

# **2574<sup>TM</sup>** **BALEBUSTER**



## *Operating Instructions*



## *and Parts Reference*





0500158 • June 2025

DuraTech Industries International Inc.  
PO Box 1940, Jamestown, ND 58402-1940

Tel: (701)-252-4601

[www.duratechindustries.net](http://www.duratechindustries.net) [www.haybuster.com](http://www.haybuster.com)





# ***2574<sup>™</sup> BALEBUSTER***

## ***Operating Instructions***



## ***and Parts Reference***


DuraTech Industries International Inc. (DuraTech Industries) has made every effort to assure that this manual completely and accurately describes the operation and maintenance of the 2574 BALEBUSTER<sup>™</sup> as of the date of publication. DuraTech Industries reserves the right to make updates to the machine from time to time. Even in the event of such updates, you should still find this manual to be appropriate for the safe operation and maintenance of your unit.

This manual, as well as materials provided by component suppliers to DuraTech Industries are all considered to be part of the information package. Every operator is required to read and understand these manuals, and they should be located within easy access for periodic review.




are registered trademarks of DuraTech Industries International, Inc. 2574 and BALEBUSTER are trademarks of DuraTech Industries International, Inc. STRAW CANNON® and logo are registered trademarks of Duratech Industries International, Inc











# ***2574™ BALEBUSTER***

## ***Operating Instructions***




DuraTech Industries International Inc. (DuraTech Industries) has made every effort to assure that this manual completely and accurately describes the operation and maintenance of the 2574 BALEBUSTER™ as of the date of publication. DuraTech Industries reserves the right to make updates to the machine from time to time. Even in the event of such updates, you should still find this manual to be appropriate for the safe operation and maintenance of your unit.

This manual, as well as materials provided by component suppliers to DuraTech Industries are all considered to be part of the information package. Every operator is required to read and understand these manuals, and they should be located within easy access for periodic review.

 &  are registered trademarks of DuraTech Industries International, Inc. 2574 and BALEBUSTER are trademarks of DuraTech industries International, Inc. STRAW CANNON® and logo are registered trademarks of Duratech Industries International, Inc





## FOREWORD



## Foreword

All personnel must read and understand the following sections before operating the *BALEBUSTER™*.

- Section 2, "Dealer Preparation," to verify that the machine has been prepared for use.
- Section 3, "Operation," which explain normal operation of the machine.
- Foreword and Section 1, important safety information.
- Section 3.1, "Pre-Operation Inspection".


### Appropriate use of unit

Your model 2574™ *BALEBUSTER™* is designed to load and shred most types of baled livestock forage. It is designed specifically for use on 6 foot. diameter round bales weighing up to 2,000 pounds and 5-1/2 feet in length

To avoid possible damage to the machine and risk of injury to the operator, consult with a DuraTech representative before attempting to shred materials other than livestock forage.

The *BALEBUSTER* has multiple uses:

- Laying forage windrows in open fields.
- Filling feed bunks - fenceline, circular etc.
- Spreading straw for livestock bedding.
- Spreading mulch over perennial plants, such as strawberries, mushrooms, etc.
- Spreading mulch over reclaimed land areas.
- Spreading mulch over sugar beets for storage.




## Operator protection

As with all machinery, care needs to be taken in order to insure the safety of the operator and those in the surrounding area.




**WARNING:** The **OPERATOR IS RESPONSIBLE** for the safety of the operator and those in the surrounding area. Operators of the **BALEBUSTER** are required to wear head, eye, and ear protection, No loose clothing is allowed.




## TABLE OF CONTENTS

<b>Part 1: Operating Instructions .....</b>	<b>2</b>
<b>Introduction .....</b>	<b>2</b>
<b>Appropriate use of unit .....</b>	<b>2</b>
<b>Purpose .....</b>	<b>2</b>
<b>How to use this manual .....</b>	<b>3</b>
 <b>Section 1: Safety.....</b>	<b>4</b>
1.1 Safety-alert symbols .....	4
1.2 Operator - personal equipment.....	6
1.3 Machine safety labels .....	7
1.4 Shielding.....	9
1.5 Personal equipment .....	9
1.6 Safety review .....	9
1.7 Towing/road transport .....	11
 <b>Section 2: Dealer preparation .....</b>	<b>12</b>
2.1 Assembly required.....	12
2.2 Pre-delivery inspection.....	12
2.3 Machine operation check.....	13
2.4 Loader tines.....	14
 <b>Section 3: Operation .....</b>	<b>15</b>
3.1 Pre-operation inspection .....	16
 3.2 Introduction to the machine .....	17
3.2.1 Operator controls.....	17
3.2.2 Bale conveyor.....	17
3.2.3 Rotor.....	17
3.2.4 Auger .....	18
3.2.5 Slug bars .....	18
3.2.6 Screen .....	18
3.2.7 Fan.....	18
3.2.8 Discharge spout and deflector .....	18
 3.3 Machine Operation & Adjustments.....	19
3.3.1 Tractor Set Up .....	19
3.3.2 Hitching the BALEBUSTER to a tractor .....	20
3.3.2A Movable Hitch .....	20
3.3.3 Starting the machine.....	21
3.3.4 Normal shut-down procedure.....	22
3.3.5 Unhitching the BALEBUSTER from a tractor .....	22



## TABLE OF CONTENTS

3.3.6 P.T.O. Shield and Belt Access Cover .....	23
3.3.7 Conveyor Chain Adjustment.....	24
3.3.8 Adjusting Belt Tension.....	25
3.3.9 Slugbar Adjustment.....	26
3.3.10 Clean Out Door.....	27
3.3.11 Flails.....	27
3.3.12 Loader.....	28
3.3.13 Loading the bale .....	30
3.3.14 Operating the machine.....	31
3.3.15 Loader Transport Pin .....	31
3.3.16 Hydraulic Cylinder and Valve .....	31
3.3.18 Rack.....	32
3.3.17 Tires and Rims .....	32
3.3.18A Rack Tool.....	33
3.3.19 Jack .....	34
3.3.20 Hooking up hydraulic control box and hydraulics to tractor.....	34
3.3.21 Fan .....	35
<b>3.4 Adjusting the machine.....</b>	<b>36</b>
3.4.1 Changing the output distribution pattern .....	36
3.4.2 Changing length of cut.....	37
3.4.3 Changing screens .....	37
3.4.4 Adjusting the bale conveyor speed.....	37
3.4.5 Changing the slug bar settings .....	38
<b>3.5 Road transport .....</b>	<b>38</b>
3.5.1 Preparing the BALEBUSTER for transport.....	38
3.5.2 Changing Back To Operate .....	39
<b>3.6 Storage.....</b>	<b>39</b>
3.6.1 Preparing the machine for storage .....	39
3.6.2 Removing the machine from storage .....	40
<b>Section 4: General maintenance .....</b>	<b>41</b>
4.1 Lubrication .....	41
4.1.1 LUBRICATION POINTS.....	41
4.2 Axle, wheels, tires.....	48
4.3 Conveyor chain tension .....	48
4.4 Belt Bushing Torque Settings.....	48
4.5 General appearance.....	48



**TABLE OF CONTENTS**

**Section 5: Troubleshooting..... 49**


**Appendix A: WARRANTY..... 50**

**Appendix B: 2574 BALEBUSTER Specifications ..... 51**

**Appendix C: Options ..... 52**

**Appendix D: Required For Operation ..... 53**

**Appendix E: 2574 BALEBUSTER SHIPPING LIST ..... 54**



# Introduction

## Appropriate use of unit

Your model 2574™ BALEBUSTER™ is designed to load and shred most types of baled livestock forage. It is designed specifically for use on 6 foot. diameter round bales weighing up to 2,000 pounds and 5-1/2 feet in length



**NOTE:** To avoid possible damage to the machine and risk of injury to the operator, consult with a DuraTech Industries International, Inc. (DuraTech Industries) representative before attempting to shred materials other than livestock forage.

The 2574 BALEBUSTER has multiple uses:

- Laying forage windrows in open fields.
- Filling feed bunks - fenceline, circular etc.
- Spreading straw for livestock bedding.
- Spreading mulch over perennial plants, such as strawberries, mushrooms, etc.
- Spreading mulch over reclaimed land areas.
- Spreading mulch over sugar beets for storage.

## Purpose

The purpose of this owner's manual is to explain maintenance requirements and routine adjustments for the most efficient operation of your 2574 BALEBUSTER. There is also a trouble shooting section that may help in case of problems in the field. Any information not covered in this manual may be obtained from your dealer.




**SPECIAL NOTE:** When reference is made as to front, rear, left hand, or right hand of this machine, the reference is always made from standing at the rear end of the machine and looking toward the hitch. Always use serial number and model number when referring to parts or problems. Please obtain your serial number and write it below for your future reference.

MODEL: 2574 BALEBUSTER

SERIAL NO. \_\_\_\_\_





## **How to use this manual**

### **Manual organization**

This manual is organized into the following parts:


- Part 1: Operating instructions explain how to set up, use and maintain the 2574 BALEBUSTER.
- Part 2: Parts reference contains diagrams of each assembly, with the part number of each part. A key on the facing page contains a description of the part and the quantity used.

### **Dealer responsibilities**

- Read Section 2, “Dealer Preparation,” and perform the tasks outlined. Also perform a pre-operation inspection as described in Section 3.1.
- Upon delivery of the unit to the customer, it is your responsibility to conduct a training session on the safe operation of the unit for the primary operator(s). You must also conduct a “walk-around” inspection of all safety instructional decals on the machine itself. Decals are illustrated in Part 2: Parts Reference.
- Complete and return the Warranty Registration Card. Receipt of this form is required to activate the warranty. Appendix A provides details of the warranty.

### **Operator responsibilities**

- Operator is responsible for his safety.
- Operator is also responsible for safety of others near the machine.
- Review Section 2, “Dealer Preparation,” to verify that the machine has been prepared for use.
- Thoroughly review sections 1 and 3, which explain normal operation of the machine, and section 4, which explain maintenance requirements.
- Note the important safety information in the Foreword and in Section 1, “Safety.”
- Keep copies of all manuals in a readily - accessible location for future reference.
- Tractor is setup according to section 3.3.1 “tractor set-up”



# Section 1: Safety

The safety of the operator is of great importance to DuraTech Industries/Haybuster. We have provided decals, shield and other safety features to aid you in using your machine safely. In addition, we ask you to be a careful operator who will properly use and service your Haybuster equipment.



**WARNING:** FAILURE TO COMPLY WITH SAFETY INSTRUCTIONS THAT FOLLOW WITHIN THIS MANUAL COULD RESULT IN SEVERE PERSONAL INJURY OR DEATH. BEFORE ATTEMPTING TO OPERATE THIS MACHINE, CAREFULLY READ ALL INSTRUCTIONS CONTAINED WITHIN THIS MANUAL. ALSO READ THE INSTRUCTION MANUAL PROVIDED WITH YOUR TRACTOR.

**THIS MACHINE IS NOT TO BE USED FOR ANY PURPOSE OTHER THAN THOSE EXPLAINED IN THE OPERATOR'S MANUAL, ADVERTISING LITERATURE OR OTHER DURATECH INDUSTRIES WRITTEN MATERIAL PERTAINING TO THE 2574 BALEBUSTER.**

## 1.1 Safety-alert symbols

Decals are illustrated in **Part 2: Parts Reference**.

The safety decals located on your machine contain important and useful information that will help you operate your equipment safely.

To assure that all decals remain in place and in good condition, follow the instructions below:


- Keep decals clean. Use soap and water - not mineral spirits, adhesive cleaners and other similar cleaners that will damage the decal.
- Replace all damaged or missing decals. When attaching decals, surface temperature of the machine must be at least 40° F (5° C). The surface must be also be clean and dry.
- When replacing a machine component to which a decal is attached, be sure to also replace the decal.
- Replacement decals can be purchased from your Haybuster dealer.

DuraTech Industries uses industry accepted **ANSI** or **ASAE** standards in labeling its products for safety and operational characteristics.



### Safety-Alert Symbol

Read and recognize safety information. Be alert to the potential for personal injury when you see this safety-alert symbol.



**DANGER:** Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. This signal word is to be limited to the most extreme situations, typically for machine components that, for functional purposes, cannot be guarded.

**WARNING:** Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury, and includes hazards that are exposed when guards are removed. It may also be used to alert against unsafe practices.

**CAUTION:** Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

This manual uses the symbols to the right to denote important safety instructions and information.

The **DANGER**, **WARNING** and **CAUTION** symbols are used to denote conditions as stated in the text above. Furthermore, the text dealing with these situations is surrounded by a box with a white background, will begin with **DANGER**, **WARNING**, or **CAUTION**.

The **INFORMATION** symbol is used to denote important information or notes in regards to maintenance and use of the machine. The text for this information is surrounded by a box with a light grey background, and will begin with either **IMPORTANT** or **NOTE**.



**DANGER:**

Signal word - White Lettering/Red Background

Safety Alert Symbol - White Triangle/Red Exclamation Point



**WARNING:**

Signal word - Black Lettering/Orange Background

Safety Alert Symbol - Black Triangle/Orange Exclamation Point




**CAUTION:**

Signal word - Black Lettering/Yellow Background

Safety Alert Symbol - Black Triangle/Yellow Exclamation Point



	1. Yellow warning triangle/black graphical symbol, indicates what the hazard is. Hazard Identification
	2. Red circle-with-slash/black graphical symbol indicates a prohibited action to avoid the hazard. Prohibited Action
	3. Blue mandatory action circles/white graphical symbol - indicates an action to take to avoid the hazard. Mandatory Action



## 1.2 Operator - personal equipment

### THE OPERATOR

#### Physical Condition

You must be in good physical condition and mental health and not under the influence of any substance (drugs, alcohol) which might impair vision, dexterity or judgment.

Do not operate a **2574 BALEBUSTER** when you are fatigued. Be alert - If you get tired while operating your **2574 BALEBUSTER**, take a break. Fatigue may result in loss of control. Working with any farm equipment can be strenuous. If you have any condition that might be aggravated by strenuous work, check with your doctor before operating

#### Proper Clothing



Clothing must be sturdy and snug-fitting, but allow complete freedom of movement. Avoid loosefitting jackets, scarfs, neckties, jewelry, flared or cuffed pants, unconfined long hair or anything that could become entangled with the machine.



Protect your head with a hard hat to reduce the risk of injury from flying debris.



Protect your hands with gloves when handling flail and sections. Heavyduty, nonslip gloves improve your grip and protect your hands.




Good footing is most important. Wear sturdy boots with nonslip soles. Steel-toed safety boots are recommended.



To reduce the risk of injury to your eyes never operate a **2574 BALEBUSTER** unless wearing goggles or properly fitted safety glasses with adequate top and side protection.




Tractor noise may damage your hearing. Always wear sound barriers (ear plugs or ear muffers) to protect your hearing. Continual and regular users should have their hearing checked regularly.



## 1.3 Machine safety labels

The safety decals located on your machine contain important information that will help you operate your equipment. Become familiar with the decals and their locations.



**DANGER:** FLYING HAY, ROCKS, AND OTHER OBJECTS THROWN BY MACHINE.

STAY CLEAR OF DISCHARGE SIDE OF MACHINE UNLESS OPERATOR HAS STOPPED TRACTOR ENGINE AND MACHINE HAS STOPPED ROTATING. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN SEVERE PERSONAL INJURY OR DEATH.

**⚠ DANGER**



**FLYING HAY, ROCKS, AND OTHER OBJECTS THROWN BY MACHINE.**

STAY CLEAR OF DISCHARGE SIDE OF MACHINE UNLESS OPERATOR HAS STOPPED TRACTOR ENGINE AND MACHINE HAS STOPPED ROTATING.

FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN SEVERE PERSONAL INJURY OR DEATH.

**⚠ PELIGRO**




**LA PAJA, LAS PIEDRAS Y OTRAS COSAS TIRADAS POR LA MAQUINA.**

NO SE PARE JUNTO AL LADO DE PARADOR DE LA MAQUINA SI EL MOTOR ESTÁ EN MARCHA Y LAS PALETAS ESTÁN EN MOVIMIENTO.

NO SEGUIR ESTAS INSTRUCCIONES PUEDE RESULTAR EN HERIDAS GRAVES E INCLUSO LA MUERTE.

6500034



**DANGER:** ROTATING FLAILS CAN KILL OR DISMEMBER

KEEP CLEAR OF MACHINE UNTIL POWER TAKE-OFF HAS BEEN DISENGAGED, TRACTOR ENGINE SHUT OFF AND FLAIL ROTATION STOPPED

**⚠ DANGER**


**ROTATING FLAILS CAN KILL OR DISMEMBER**

KEEP CLEAR OF MACHINE UNTIL POWER TAKE-OFF HAS BEEN DISENGAGED, TRACTOR ENGINE SHUT OFF AND FLAIL ROTATION STOPPED

**LAS PALETAS EN MOVIMIENTO PUEDEN DISMEMBRAR E INCLUSO MATAR**

MANTENGA SU DISTANCIA HASTA QUE SE DESCONECTE LA TONDA DE FUERZA. EL MOTOR PARE Y LAS PALETAS DEJEN DE MOVERSE

6500035




**DANGER:** ROTATING DRIVELINE, KEEP AWAY! ENTANGLEMENT CAN CAUSE SERIOUS INJURIES OR DEATH.

**DO NOT OPERATE WITHOUT**

- ALL DRIVELINE GUARDS, TRACTOR AND EQUIPMENT SHIELDS IN PLACE
- DRIVELINES SECURELY ATTACHED AT BOTH ENDS
- DRIVELINE GUARDS THAT TURN FREELY ON DRIVELINE

**⚠ DANGER**




**Rotating Driveline Keep Away!**

Entanglement can cause serious injuries or death.

**Do Not Operate Without -**

- \* All driveline guards, tractor and equipment shields in place.
- \* Drivelines securely attached at both ends.
- \* Drivelines guards that turn freely on driveline.

6500085




**DANGER:** ROTATING PARTS WITHIN CAN KILL OR DISMEMBER. WAIT FOR ALL MOVEMENT TO STOP BEFORE SERVICING, UNLOADING, OR INSPECTING MACHINE.

**⚠ DANGER**

**ROTATING PARTS WITHIN CAN KILL OR DISMEMBER**

WAIT FOR ALL MOVEMENT TO STOP BEFORE SERVICING, UNLOADING OR INSPECTING MACHINE

6500082



**WARNING:** FOR YOUR PROTECTION KEEP ALL SHIELDS IN PLACE AND SECURED WHILE MACHINE IS OPERATING MOVING PARTS WITHIN CAN CAUSE SEVERE PERSONAL INJURY.



**WARNING:** FOR YOUR PROTECTION AND PROTECTION OF OTHERS, **PRACTICE THE FOLLOWING SAFETY RULES.**

1. BEFORE OPERATING THIS MACHINE, READ THE OPERATOR'S MANUALS SUPPLIED WITH THIS MACHINE AND YOUR TRACTOR.
2. CHECK OPERATORS MANUALS TO BE SURE YOUR TRACTOR MEETS THE MINIMUM REQUIREMENTS FOR THIS MACHINE.
3. READ ALL DECALS PLACED ON THIS MACHINE FOR YOUR SAFETY AND CONVENIENCE.
4. NEVER ALLOW RIDERS ON THIS IMPLEMENT OR THE TRACTOR.
5. KEEP OTHERS AWAY FROM THIS MACHINE WHILE IN OPERATION.
6. KEEP ALL SHIELDS IN PLACE WHILE MACHINE IS OPERATING.
7. KEEP HANDS, FEET, LOOSE CLOTHING, ETC., AWAY FROM POWER DRIVEN PARTS.
8. ALWAYS SHUT OFF MACHINE AND ENGINE BEFORE SERVICING, UNCLOGGING, INSPECTING, OR WORKING NEAR THIS MACHINE FOR ANY REASON. ALWAYS PLACE TRANSMISSION IN PARK OR SET PARK BRAKE AND WAIT FOR ALL MOVEMENT TO STOP BEFORE APPROACHING THIS MACHINE.



- WARNING:**
- RISK OF HEAD AND EYE INJURIES.
  - RISK OF HEARING DAMAGE.

HEAD, EYE, AND HEARING PROTECTION REQUIRED.



**WARNING:** Moving parts can crush and cut. Keep hands clear.



**WARNING**



**ADVERTENCIA**

FOR YOUR PROTECTION KEEP ALL SHIELDS IN PLACE AND SECURED WHILE MACHINE IS OPERATING. MOVING PARTS WITHIN CAN CAUSE SEVERE PERSONAL INJURY.

PARA ASEGURAR SU PROTECCION, MANTENGA TODOS LOS PROTECTORES EN SU LUGAR Y ASEGURADOS MIENTRAS LA MAQUINA ESTE OPERANDO. LAS PIEZAS MOVILES INTERNAS PUEDEN CAUSAR LESIONES PERSONALES GRAVES.

6500040

6500040



**WARNING**



**ADVERTENCIA**

FOR YOUR PROTECTION AND PROTECTION OF OTHERS, PRACTICE THE FOLLOWING SAFETY RULES.

1. BEFORE OPERATING THIS MACHINE, READ THE OPERATOR'S MANUALS SUPPLIED WITH THIS MACHINE AND YOUR TRACTOR.
2. CHECK OPERATORS MANUALS TO BE SURE YOUR TRACTOR MEETS THE MINIMUM REQUIREMENTS FOR THIS MACHINE.
3. READ ALL DECALS PLACED ON THIS MACHINE FOR YOUR SAFETY AND CONVENIENCE.
4. NEVER ALLOW RIDERS ON THIS IMPLEMENT OR THE TRACTOR.
5. KEEP OTHERS AWAY FROM THIS MACHINE WHILE IN OPERATION.
6. KEEP ALL SHIELDS IN PLACE WHILE MACHINE IS OPERATING.
7. KEEP HANDS, FEET, LOOSE CLOTHING, ETC., AWAY FROM POWER DRIVEN PARTS.
8. ALWAYS SHUT OFF MACHINE AND ENGINE BEFORE SERVICING, UNCLOGGING, INSPECTING, OR WORKING NEAR THIS MACHINE FOR ANY REASON. ALWAYS PLACE TRANSMISSION IN PARK OR SET PARK BRAKE AND WAIT FOR ALL MOVEMENT TO STOP BEFORE APPROACHING THIS MACHINE.

SIGA LAS REGLAS SIGUIENTES DE SEGURIDAD PARA SU PROTECCION Y LA PROTECCION DE OTROS


1. LEA LOS MANUALES DEL OPERADOR INCLUIDOS CON ESTA MAQUINA Y SU TRACTOR ANTES DE OPERAR ESTA MAQUINA.
2. PARA ASEGURARSE QUE SU TRACTOR CUMPLE CON LOS REQUERIMIENTOS MINIMOS PARA ESTA MAQUINA, REVISE LOS MANUALES DEL OPERADOR.
3. PARA SU SEGURIDAD Y CONVENIENCIA, LEA TODAS LAS CALCOMANIAS COLOCADAS EN LA MAQUINA.
4. NUNCA PERMITA PASAJEROS EN ESTA MAQUINA O EN EL TRACTOR.
5. MANTENGA ALEJADOS A LOS ESPECTADORES MIENTRAS ESTA MAQUINA ESTE OPERANDO.
6. MANTENGA TODOS LOS PROTECTORES EN SU LUGAR MIENTRAS LA MAQUINA ESTE OPERANDO.
7. MANTENGA LAS MANOS, PIES, ROPAS HOLGADAS, ETC., ALEJADAS DE LAS PIEZAS PROPULSADAS.
8. SIEMPRE APAGUE LA MAQUINA Y EL MOTOR ANTES DE PRESTAR SERVICIO, DESHERRAM, INSPECCIONAR O TRABAJAR CERCA DE ESTA MAQUINA POR CUALQUIER MOTIVO. ANTES DE ACERCARSE A ESTA MAQUINA COLOQUE SIEMPRE LA TRANSMISION EN ESTACIONAMIENTO O ENGANCHE EL FRENO DE ESTACIONAMIENTO.

6500041

6500041




6500549




6500488





**CAUTION:** ADJUST TRACTOR DRAWBAR SO THAT THE DISTANCE FROM THE END OF THE P.T.O. SHAFT ON THE TRACTOR TO THE CENTER OF THE DRAWBAR HITCH PIN IS 16".



⚠ CAUTION	⚠ PRECAUCIÓN
<ol style="list-style-type: none"><li>1. ADJUST TRACTOR DRAWBAR SO THAT THE DISTANCE FROM THE END OF THE PTO SHAFT ON THE TRACTOR TO THE CENTER OF THE DRAWBAR HITCH PIN IS 16".</li><li>2. ADJUST THE HITCH CLEVIS SO THE MACHINE IS PARALLEL WITH THE GROUND WHEN HITCHED TO TRACTOR.</li><li>3. HITCH MACHINE TO TRACTOR WITH A 1" HITCH PIN AND SECURE TO PREVENT LOSS.</li><li>4. ADJUST PTO BEARING BRACKET SO THE SHAFT ON THE MACHINE IS LEVEL WITH THE PTO SHAFT ON THE TRACTOR.</li></ol>	<ol style="list-style-type: none"><li>1. AJUSTAR LA BARRA DE TIRO DEL TRACTOR DE MODO QUE LA DISTANCIA DEL EXTREMO DEL EJE DE LA TÍP DEL TRACTOR AL CENTRO DEL PASADOR DEL ENGANCHE DE LA BARRA DE TIRO SEA DE 16 PULG.</li><li>2. AJUSTAR LA HORQUILLA DEL ENGANCHE DE MODO QUE LA MÁQUINA QUEDA PARALELA CON EL SUELO CUANDO ESTE ENGANCHADA AL TRACTOR.</li><li>3. ENGANCHAR LA MÁQUINA AL TRACTOR CON UN PASADOR DE ENGANCHE DE 1 PULG (25.4 MM) Y FIJARLO PARA EVITAR LA DECONEXIÓN.</li><li>4. AJUSTAR LA ESCUADRA DEL CUNETIL DE LA TÍP DE MODO QUE EL EJE DE LA MÁQUINA QUEDA AL MISMO NIVEL CON EL EJE DE LA TÍP DEL TRACTOR.</li></ol>

SEE OWNERS MANUAL FOR MORE INFORMATION

VER EL MANUAL DEL OPERADOR PARA MÁS INFORMACIÓN.

6500322

- Replacement decals can be purchased from your Haybuster dealer.

## 1.4 Shielding

Shields are installed for your protection. Keep them in place, and replace damaged shields.

## 1.5 Personal equipment

Operators of this machine are encouraged to wear head, eye, and ear protection. Operators should not wear loose clothing.

## 1.6 Safety review

### BEFORE OPERATING THE MACHINE


- Read and follow all instructions contained in:
  - A. This 2574 BALEBUSTER Operator's manual
  - B. Tractor Operator's manual
  - C. Decals placed on the 2574 BALEBUSTER



**NOTE:** Additional copies of the above mentioned materials can be obtained from your dealer.

- Allow only responsible, properly instructed individuals to operate your machine. Carefully supervise inexperienced operators.
- Use a tractor which meets the tractor requirements contained within this manual. **See Appendix D., Required For Operation:**
- Make sure the machine is in good operating condition and that all protective shields are in place and in proper working order. Replace damaged shields before operating.
- Make no modifications to the machine unless specifically recommended or requested by DuraTech Industries.
- Check periodically for broken or worn parts and make any necessary repairs.
- If required install the PTO safety chain. Check local regulations regarding safety chain requirements.





## DURING OPERATION

Enforce the following safety precautions and others contained in this manual to prevent serious personal injury.

- Everyone must be kept clear of work area except operator seated at tractor controls.
- Disengage PTO before starting engine.
- **Never work on or near BALEBUSTER unless engine is shut off and flails have stopped.**
- Keep shields in place and in good condition.
- Watch out for and avoid any object that might interfere with the proper operation of the machine.
- Power takeoff shafts must be locked in place with protective PTO shields in place.
- Keep hands, feet and clothing away from power driven parts.
- **Never leave tractor controls unattended while the engine is running.**
- Exercise extreme care when operating on rough and/or steep terrain. Avoid operation on terrain which is excessively rough or steep.
- **Make sure your tractor PTO speed never exceeds 1000 RPM.**

## WHEN PERFORMING SERVICE AND MAINTENANCE




**CAUTION:** Before performing any maintenance or adjustments make sure machine is NOT running. If for any reason arc welding is to be done, always ground the welder close to the point where the welding is being done. It is recommended that the rotor be grounded to frame of machine to prevent arcing on bearings.

- Before working on or near the BALEBUSTER for any reason, including servicing, cleaning, unplugging or inspecting machine, use normal shut-down procedures unless instructed differently in this manual.
- Use only replacement parts that are provided by DuraTech Industries.
- If it is necessary to operate the tractor engine indoors for more than a few seconds, be sure to provide enough ventilation to remove the tractor exhaust fumes.
- Relieve all pressure in the hydraulic system before disconnecting the hose or performing other work on the system. Make sure all connections are tight and the hose is in good condition before applying pressure to the system.



**WARNING:** Hydraulic fluid escaping under pressure can be visible and have enough force to penetrate the skin. When searching for a suspected leak, use a piece of wood or cardboard rather than your hands. If injured, seek medical attention immediately to prevent serious infection or reaction.


- **Never work on the BALEBUSTER with the bale loader in the raised position. Lower the bale loader to ground level.**
- Check for loose or badly worn bolts or connectors.



- Check for loose or misaligned sprockets on bale conveyor.
- Follow Lubrication Instructions.
- Inspect rotor and all rotating parts for twine or wire build-up. REMOVE DAILY
- Check air pressure in tires, inflate to the tire manufacturers recommended psi. The manufacturers recommended psi will be listed on the side wall of the tire.
- Check wheel bearings, and seals.
- Check flail bolts and tighten flail knife anchor bolts to 156 ft. lbs (21.6 kg-m) torque. Flail should pivot on the bushing not on the bolt. Flail bolts are 5/8"x4", Gr 8 fine thread.


## 1.7 Towing/road transport

Figure 1.1  
Rack, discharge spout  
and fan housing in the  
transport position



This machine is designed to fold for ease of transportation and storage. The rack assembly folds inside of bale chamber. A commercial driver's license may be required to tow this unit on public roads; verify with traffic control or licensing authorities.


- Use good judgment and drive slowly over rough or uneven terrain.
- Be sure tractor brakes are properly adjusted and foot pedals are locked together.
- When preparing implement for transport, it is recommended that the tines be removed or a pin be removed on each tine so they can pivot into the bale chamber.
- The discharge spout must be rotated to an upright position, and the fan housing must be locked in position with the strap bolted on the right side of the main frame (see Figure 1.1).
- Check your state laws regarding the use of lights, slow moving vehicle signs, safety chain and other possible requirements.



## Section 2: Dealer preparation

### 2.1 Assembly required

1. Hitch the BALEBUSTER to the tractor drawbar. Adjust the hitch so machine is parallel with ground.
2. Raise the jack. Pull the lock pin and store in the transport position.
3. Mount fork tines to loader frame..
4. Attach the PTO shaft to the tractor PTO shaft.  
Depress coupling and slide the coupling onto the splined shaft. Make sure the spring loaded safety catch is properly seated.
5. Pull rack assembly into operating position.
6. If required, install the safety chain. Check local regulations regarding safety chain requirements.
7. Grease PTO before use.
8. This machine is set up to operate on 1000 RPM only!




For more information  
see section 3.3.1 "Tractor  
Set Up"

safe distance from PTO

### 2.2 Pre-delivery inspection

**INSTRUCTIONS:** Before delivering the machine, check the following items carefully and make corrections when necessary. Place an "X" in the box after each item has been checked and found to be acceptable.

- ☐ Missing items or damage in transit.
- ☐ Loose bolts or set screws.
- ☐ Hydraulics components for leaks or damage.
- ☐ Lug bolts for tightness.
- ☐ Tires for proper air pressure.
- ☐ Condition of tire rims.
- ☐ Proper lubrication.
- ☐ All chains for proper adjustment.
- ☐ All shields for installation and condition.
- ☐ Condition of all decals.
- ☐ All phases of operation.
- ☐ Check for loose flail bolts, torque to 150 ft. lbs (21.5 kg-m).



## 2.3 Machine operation check

With Tractor hooked up to the BALEBUSTER, try all functions on the machine.



**WARNING:** The electric\hydraulic system is polarity sensitive, reversing polarity will cause damage to the solenoid P/N (4000174)



**CAUTION:** The electric\hydraulic system has a check valve installed on the valve. Oil will flow only one direction from the tractor thru the valve.

**With the engine off and key removed from the switch:**

1. Adjust the spout, the fan housing should turn.
2. Adjust the deflector tip on the spout.
3. Adjust the slug bar


**With the engine at idle:**


1. Raise and lower the loading arms.
2. Adjust the spout if equipped with the hydraulic motor option.
3. Engage the bale conveyor, adjust conveyor speed control valve on the BALEBUSTER.
4. Engage the tractor PTO, the rotor, transfer auger, and fan should be running. Listen for any odd noises and vibrations.

### Three Pin Socket

An auxiliary power connection is provided inside the operators compartment for connecting monitors, implement controllers, C.B. radios and other 12-volt equipment.

The three pin outlet is located on the right hand side to the rear of the seat. The outlet has a ground terminal and two 12-volt power terminals. One power terminal is through the key switch and the other is direct power.






## 2.4 Loading tines



For shipping purposes the loading tines are placed on the loader as shown above.

After receiving the machine the loading tines need to be removed and put into the working position. See section **3.3.12 Loader** for setting the position of tines for bales.





## Section 3: Operation

To insure long life and economical operation, we highly recommend the operator of the BALEBUSTER be thoroughly instructed in the maintenance and operation of the machine.

There is no substitute for a sound preventative maintenance program and a well trained operator.

**Figure 3.1**  
Location of major  
components





### 3.1 Pre-operation inspection

Prior to starting the engine of the tractor, we recommend the operator make a visual inspection of the unit. This can be done as the lubrication is being carried out. Any items that are worn, broken, missing or needing adjustment must be serviced accordingly before operating the BALEBUSTER.



**WARNING:** Before inspecting the machine, use the normal shut-down procedure in section 3.3.4.

Check the following:


- ☐ Transfer auger and screen for material buildup, and chunks from screen that have fallen into the transfer auger.
- ☐ Condition of flails and attachment bolts. Flail nuts are to be tightened to 150 ft. lbs (21.5 kg-m).
- ☐ Rotor for twine build-up.
- ☐ Chains for proper tension, and condition.
- ☐ Keep auger pan door closed during operation
- ☐ Check for loose bolts, worn or broken parts.
- ☐ All lubrication points have been serviced.
- ☐ Lug nuts for tightness.
- ☐ Condition of tire rims.
- ☐ Tires for proper air pressure.
- ☐ Installation of slow moving vehicle (SMV) sign if required.
- ☐ Installation and condition of shields.
- ☐ Condition of decals.
- ☐ Hydraulic components for leaks or damage.



**WARNING:** Hydraulic fluid escaping under pressure can be almost invisible and can have sufficient force to penetrate the skin. When searching for suspected leaks, use a piece of wood or cardboard rather than your hands. If injured, seek medical attention immediately to prevent serious infection or reaction.

- ☐ Test run the BALEBUSTER before loading. To prevent damaging the BALEBUSTER always engage PTO with engine idling. Look for excessive vibration, loose or broken parts. Make any necessary repairs before attempting to do any bale feeding.





## 3.2 Introduction to the machine

### 3.2.1 Operator controls

#### Operator controlled items:

- The loading tines, to load the bale. See section 3.3.6, “Loading”
- The PTO shaft, which runs the fan, auger, and rotor.
- The bale conveyor chain.

#### Adjustable items:


- The conveyor speed control valve. See section 3.4.4, “Adjusting the bale conveyor speed”
- Slug bar setting
- Screen size
- Spout and spout deflector settings

### 3.2.2 Bale conveyor

The Bale conveyor keeps the bale moving into the flails, forcing the bale to rotate, and keeping product in front of the flails

Bale conveyor speed is set with the conveyor speed control valve or tractor controls if equipped with a PFC system.


To chop the forage finer, decrease the conveyor speed by rotating the control lever up and to the left. For a coarser cut, increase the conveyor speed by rotating the lever to the right and down.



bale conveyor  
speed control  
valve

### 3.2.3 Rotor


The rotor flails shred the bale and throws the material into the augers. Rotor speed should remain constant, which is done by keeping the tractor PTO at 1000 RPM.



### 3.2.4 Auger

Transfers material from rotor chamber to fan, driven by the rotor.

**Figure 3.2**  
Rotor, bale conveyor,  
slug bars, and the  
screen



### 3.2.5 Slug bars

The 2574 BALEBUSTER comes standard with 9 slug bars. The slug bars control the depth that the flails cut into a bale as it is being shredded. As the depth of the cut becomes larger, the output becomes coarser. The depth of cut is controlled by the slug bar ratchet. For more information, see section 3.4.5 on changing the slug bar settings.

### 3.2.6 Screen


Screens are used in the 2574 to regulate product size. Screen sizes are 4-1/4"x10-1/2", and 6-1/2"x10-1/2" openings. The larger the hole, the coarser the product. Screens can be reversed when one edge becomes worn. See section 3.4.3 on changing screens.

### 3.2.7 Fan

Material goes through fan and is blown out discharge. Driven by PTO.

### 3.2.8 Discharge spout and deflector

The discharge spout and deflector assembly can be adjusted for different scattering effects. Raise the deflector for a wider spread. Lower the deflector for a narrower windrow. Rotate the discharge spout and fan housing for distribution near the machine or farther out.



## 3.3 Machine Operation & Adjustments

### 3.3.1 Tractor Set Up

A tractor drawbar and 3-point arms can cause interference with the PTO driveline IID (Implement Input Driveline). This interference can cause serious damage to the IID guarding and the IID telescoping members.

If this implement is attached to a tractor with a clevis hitch (hammer strap) style drawbar, the hammer-strap must be removed to prevent damage to the IID guarding and the IID telescoping members. See Figure 1.




Figure 1

If this implement is attached to a tractor with an offset in the drawbar, be certain it is in the down position to prevent damage to the IID guarding and the IID telescoping members. See Figure 2.





Figure 2


If this implement is attached to a tractor with 3-point arms, the arms must be fully raised and locked in position to prevent damage to the IID guarding and the IID telescoping members.

### Hitch Adjustment

The hitch is adjustable so that the machine is parallel to the ground when attached to the tractor drawbar. This is accomplished by removing the two mounting bolts and reinstalling them with the hitch at the proper height. The distance from the end of the P.T.O. shaft on the tractor to the center of the drawbar hitch pin hole should be 16" (41 cm.), and the height from the top of the drawbar to the centerline of the P.T.O. should be 8". **Refer to Page 20.**

The hitch pin should be of proper size to prevent movement and length to extend through all components of the hitch. The pin should be secured with a hairpin clip or suitable device to prevent the loss of the pin.






### 3.3.2 Hitching the BALEBUSTER to a tractor

To hitch the BALEBUSTER to a tractor, perform the following steps:

1. Adjust jack for tractor height
2. Position tractor so hitch pin can be installed, and install the hitch pin.
3. Adjust jack so that the jackstand is loose. Then place jackstand in the raised and locked position.
4. Attach PTO to tractor.
5. Clean off the hydraulic hose ends and tractor couplings, then attach the hydraulic hoses.
6. Verify hydraulic hoses are hooked up in proper orientation.
7. Raise loading table before moving.



PTO

front jack stand (hitched position)

#### 3.3.2A Movable Hitch

The 2574 BALEBUSTER is equipped with a two position moveable hitch, a transporting position and a working position.

When the hitch is in the transporting position, the 2574 BALEBUSTER will center the machine behind the tractor. In the working position the 2574 BALEBUSTER will follow off to the right of the tractor.


To change the positions of the hitch, loosen the 1" diameter bolts, top lock nuts and remove the clevis and hair pin. For the working position, move the hitch so that it is straight out from the machine and the brace lines up with the hole closest to the machine. Replace the clevis pin and hair pin in the hole and tighten the 1" diameter bolts and top lock nuts. For the transport position, move the hitch so that the brace lines up with hole closest to the front of the hitch. Replace the clevis pin and hair pin in the hole and tighten the 1" diameter bolts and top lock nuts.

Hitch shown in working position



Clevis pin & hair pin

1" Bolt and nut



### 3.3.3 Starting the machine



**WARNING:** After making all necessary hook-ups to tractor, be sure rotor chamber is clear of any solid objects. Make sure any bystanders are away from discharge before engaging PTO. Flying objects can cause serious injury or even death. Stay clear of discharge side of machine unless operator has stopped tractor engine and machine has stopped rotating. Failure to follow these instructions may result in severe injury.


#### To start the machine, perform the following steps:

1. Machine's hydraulic system performs two (2) functions. One function raises the bale loader for loading bales into the machine. The second function powers bale conveyor by means of a hydraulic motor.
2. Operating tractor PTO at 1000 RPM allows machine to do a better job of chopping forage and also keeps a minimum of twine build-up on the rotor. Twine build-up should be kept to a minimum to reduce fire hazard.
3. Always operate bale conveyor to rotate the bale in direction indicated by arrow on the front shield. Reverse direction only if the bale is lodged or hesitates to turn.



**CAUTION:** Serious injury could result if machine is allowed to tip.





### 3.3.4 Normal shut-down procedure



**WARNING:** For your safety and the safety of others, you must use the following normal shut-down procedure before leaving the tractor controls unattended for any reason, including servicing, cleaning, or inspecting the BALEBUSTER. A variation of the following procedure may be used if so instructed within this manual or your tractor manual or if an extreme emergency requires it.


**To shutdown the machine, perform the following steps:**

1. Shut hydraulic drive off for chain conveyor, and wait until the fan and auger are emptied out.
2. Reduce engine RPM to a low idle, wait for the fan to slow down. Disengage PTO.
3. Lower machine to ground level.
4. Place transmission in park or set park brake
5. Shut Off engine and remove key.
6. Wait for all movement to stop.

### 3.3.5 Unhitching the BALEBUSTER from a tractor

**To unhitch the BALEBUSTER from a tractor, perform the following steps:**

1. Follow Normal shut-down procedure
2. Lower jack and secure. Raise tongue off of the tractor draw bar
3. Detach the PTO shaft from the tractor.
4. Cycle the hydraulic control levers to release any pressure in the hydraulic hoses. Be sure loading table is completely down.
5. Detach the hydraulic hoses.
6. Detach electrical cable.
7. Remove the safety chain, if installed
8. Remove the hitch pin.
9. Place jackstand in the down and locked position. Lower BALEBUSTER into jackstand. Raise Jacks.



### 3.3.6 P.T.O. Shield and Belt Access Cover



**WARNING:** Before opening the P.T.O. and the belt access shield, be sure and follow the normal shut down procedure. Be certain that the tractor is shut off and all rotating components of the machine have come to a complete stop before opening the shield. Loose clothing is discouraged, and long hair should be restrained whenever working on the P.T.O. shafts.

To open the P.T.O. shield and belt access cover, unhook the rubber latch on the bottom of the shield and open shield as shown below.

figure 3.3a  
P.T.O. shield & belt  
access in maintenance  
position




When done working on the P.T.O. or belts, close shield and re-hook the rubber latch. As shown below.

figure 3.3b  
P.T.O. shield and belt  
access in working  
(latched) position




Rubber latch





### 3.3.7 Conveyor Chain Adjustment


The three chain tensioning bolts should be adjusted to allow lifting of the slats 1" to 1-1/2" above the conveyor deck. These bolts are located on the front of the conveyor at the center and on the rear. Bolts must be adjusted evenly. Conveyor shafts must be straight. Over tightening the center chain tensions will damage bearing and slats.



Left conveyor chain adjustment bolt




Right conveyor chain adjustment bolt



Center conveyor chain adjustment bolts


Conveyor shaft



### 3.3.8 Adjusting Belt Tension


Using the pretension angle marking located in the corner of the outer housing as a reference; loosen the center mounting bolt. With the large wrench provided, hold the outer housing and remove the index bolt. Continue turning the outer housing until the proper amount of tension has been applied, 20 to 30 degrees.

**DO NOT EXCEED 30 DEGREES OF PRE-TENSION!**



Pretension angle markings


**WRENCH**  
8102154 - Auger Drive  
8102155 - Fan



Mounting bolt

Index bolt


The tensioner mounting plates have a notch on one side, turning the mount 180 degrees will move the adjustment index holes a half step.



Tensioner mounting plate notch

For a setting that is halfway between the holes on the mounting plate, rotate the mounting plate 180 degrees and re-tension the bolts.

When belts are at the proper tension, install index bolt and tighten. Tighten the center mounting bolt and re-check pre-tension angle on the outer housing.



### 3.3.9 Slugbar Adjustment


Exposing, less flail will create a finer cut and use less horsepower, while exposing more flail will produce a coarser cut.

This is accomplished by rotating the slugbar adjustment handle. Rotating the handle counterclockwise will expose more flail, clockwise will expose less flail. To rotate the handle, squeeze the lever to release the lock and rotate the handle to the desired position, and release the lever. Be sure that the lever is seated in one of the adjustment slots to ensure that slugbars stay properly adjusted.

With the handle rotated fully clockwise the will expose the least amount of flail (position 1).


Position	Approx. Flail Exposed
1	1"
2	1-1/8"
3	1-1/4"
4	1- 3/8"
5	1-1/2"
6	1-9/16"
7	1-5/8"
8	1- 11/16"
9	1-3/4"

Positions 1 through 4 are for spreading Dry Straw. Positions 4 through 6 should only be used when grinding Dry Straw. (Use positions 6 through 9 if bale material is wet, has high moisture hay-straw.)



Shown with hydraulic slugbar adjustment






### 3.3.10 Clean Out Door



**WARNING:** Before opening the clean out door, be sure and follow the normal shut down procedure. Be certain that the tractor is shut off and all rotating components of the machine have come to a complete stop before opening clean out door.

The clean out door allows for easy access to the rotor for flail changes and twine removal. To open the door release the rubber latches. Lift open the door.

To close the door, hook the rubber latches. This should draw the door in tight. If the door is loose or can not be closed, check for obstructions. Hooks can be adjusted by screwing them in or out of the latch.



clean out door in the closed position


clean out door rubber latches


### 3.3.11 Flails

Flails must to be free to rotate about the bushings on the rotor. The bushings must not rotate. The bushings are held secure by tightening the bolts which squeeze the tabs against the bushing. Bolts should be torqued to 156 ft.-lbs. (21.5 kg-m).

figure 3.4  
rotor and flails

flail  
flail tightening bolt  
rotor





3.3.12 Loader

**WARNING:** Loader tines may swing down unexpectedly as they drop over center. They can move faster than you can react. Keep all bystanders away from the machine while loader is raised.

figure 3.5  
Loader Tines right side







figure 3.5A  
Loader Tines left side






1. The loader has three settings for different size bales. For bales approximately 72" in diameter mount the loader tines in the outermost position. 60" bales require the loader tines to be positioned in the left outer slot and the right inner slot (left and right are determined while facing in the direction of travel). 48" bales require the tines to be positioned in the inner mounting slots (see below)
2. 48" bales use left inner and right inner mounting slots.  
60" bales use left outer and right inner mounting slots (standard).  
72" bales use left outer and right outer mounting slots.



3. These settings are accomplished by removing the pivot bolts and removing the tine. After the tine is reinstalled in the proper position, reinstall the pivot bolt and tighten. Be sure the bolt threads protrude through the entire nut so that the locking nut functions properly. Do not over tighten the pivot bolt, the tine should rotate freely about the pivot bolt.
4. The loader tines should pivot freely as the loader is raised and lowered. If the loader tines don't swing down into the loading position the bale will not load properly. With the loader fully raised the loader tines should swing down.



**CAUTION:** Watch for overhead hazards such as power lines.



### 3.3.13 Loading the bale

The bale conveyor must not be running when a bale is lifted into the shredding chamber. (*step3-5*), dropping bales on to the moving conveyor slats may bend slats.



**DANGER:** If it is necessary to transport a second bale over uneven terrain, make sure any bystanders are away from the 2574 BALEBUSTER. Serious injury or death could result if the bale rolls off the loader main frame loader supports.

**STEP 1:** Lower the bale loader part way down so you can still see the end of the tine fork. Use the fork as a guide and back up to the first bale, with the bale loader in its lowest position, back up until the bale is loaded on the main frame loader supports

**STEP 2:** Slowly lift bale, until the flat end is firmly against the table. If you need to travel to the second bale, transport with the bale loader on the main frame supports, use the bale as a guide to line up the second bale.

**STEP 3-5:** Slowly lift bale into the shredding chamber. Continue lifting the bale loader until it stops. The correct position for shedding a single bale will help prevent spillage.




**NOTE:** If bale does not rotate forward the twine may be over the tine. Cut the twine at this time to prevent damage to the machine.


**STEP 6:** Load a second bale (if the first bale is on the main frame loader supports, use the bale as a guide to line up on the second bale). (If the first bale is in the shredding chamber use the conveyor and move the bale to the right so you can look past it on the left side). Back trailer until bale is loaded on the main frame loader supports. Slowly lift the bale off the ground keeping the weight of the bale on the main frame loader supports. This is the transport position for the second bale.

**STEP 7:** After the first bale is shredded, repeat steps, 3-5, loading and shredding the bale.


figure 3.6  
loading the bale




STEP 1




STEP 2




STEP 3



STEP 4




STEP 5



STEP 6





### 3.3.14 Operating the machine

To operate the machine, perform the following steps:

1. Load machine according to section 3.3.13 “Loading the bale”.
2. With tractor at half speed, engage PTO.
3. Increase tractor engine speed so PTO is at 1000 RPM.
4. Engage conveyor chain orbit motor hydraulics.
5. Drive as needed to spread as desired.

### 3.3.15 Loader Transport Pin



**WARNING:** Never stand under loader when removing transport pins. Do not attempt to force pins out, with the loader fully raised.

The loader transport pins can be inserted into three positions:

1. Upper hole: Holds the loader in the fully raised storage position.
2. Middle hole: Holds the loader partly raised. This improves rear visibility and reduces wind drag during transportation
3. Lowest hole: Holds the loader transport pin in storage position.




loader transport pin in transport position

### 3.3.16 Hydraulic Cylinder and Valve

All cylinder and valve hose connections should be tight and leak free. If the area near a hose connection becomes oily or dirty repairs should be made to seal the leak. Hoses should be free of cracks or cuts to ensure safe operation. Cylinder seal kits are available from your dealer to repair a leaky cylinder. Pin connections should be free of excessive wear. If pins become worn they should be replaced. Also check yokes and mounts for cracks and wear.



**WARNING:** Hydraulic fluid escaping under pressure can be almost invisible and can have sufficient force to penetrate the skin. When searching for suspected leaks, use a piece of wood or cardboard rather than your hands. If injured seek qualified medical attention immediately to prevent serious infection or reaction.



### 3.3.17 Tires and Rims


Tires should be inflated to 40 PSI (275 kPa) and should be free of cuts or cracks. There should also be adequate tread and no visible cords, wires or tread separation. Tires must also be of proper load rating, speed rating and size.


Rims must be free of cracks and rust pitting. Lug bolts must also be tight. Inspect the area around the lug bolts. If rust develops this is a sign of loose lug bolts. Check wheel bearings and seals, replace and grease as use requires.

### 3.3.18 Rack

The rack has two positions: transport and working. The rack should travel between the two positions freely under the operator's own power. All pivoting connections should be snug, but still allow the points to hinge freely. Inspect for cracked or excessively worn holes at the connections. The rack connection straps are designed to be self-folding and should not drop over center. If the straps become bent or do not function properly they should be replaced.

**figure 3.7**  
**rack in the working**  
**position, rack**  
**connection straps**





### 3.3.18A Rack Tool

The 2574 BALEBUSTER comes with a rack tool for unfolding the rack from the transport position. The rack tool is stored on the front of the shredder when not in use.




Rack tool in stored location



Rack tool in position for unfolding rack from transport position





### 3.3.19 Jack

An adjustable jack is provided with the machine to support the hitch when the machine is disconnected from the tractor. The jack must only be used on firm, level ground or similar base to prevent it from sinking,

When unhooking the machine remove the jack pin and rotate the jack to the upright position and reinstall the pin. Crank the jack until the hitch is no longer supported by the drawbar of the tractor. The hitch pin can now be removed.



**WARNING:** Never use the jack without reinstalling the jack pin.

When hooking up the machine, install a proper hitch pin and secure it with a hairpin clip or comparable device, crank the jack until the foot of the jack is fully raised. Remove the jack, and place in transport position.

### 3.3.20 Hooking up hydraulic control box and hydraulics to tractor

To hook up the hydraulic control box to the 2574 Balebuster, line up plug from the control box to the plug on the machine and twist together. To disconnect twist opposite direction and pull apart.

Valves on the 2574 Balebuster are protected with a one way check valve to ensure proper function.

To engage tractor hydraulics so switches function correctly, turn on and lock one hydraulic function when operating the shredder.

If the direction of the lever is not right for the tractor or does not lock, reverse the hydraulic hose hook ups on the tractor.


Recommended hydraulic flow rate is 8 to 12 gallons a minute. If hydraulic flow is too low, it will cause the hoses to pulsate and if the flow is too high, damage to the valve will occur.

To hook up to 12 volt power, one of two power plugs is needed. For newer tractors with a three prong plug a 15 amp fuse is needed. For older tractors a wiring harness can be purchased (part #5700686) using a 15 amp fuse, and plugging the harness into a keyed power source.

5701167 - control box







### 3.3.21 Fan



**WARNING:** The fan on the 2574 BALEBUSTER has an overrunning clutch. When the PTO is disengaged, the fan will continue to rotate. Follow normal shut down procedure and **WAIT** for all moving parts to **STOP**!

The fan assembly on a 2574 BALEBUSTER features bolt-in replaceable fan blades and shaft.




Bolt-in replaceable fan blade

An access cover is located on the front of the fan for replacing fan blades.

Access cover






### 3.4 Adjusting the machine

#### 3.4.1 Changing the output distribution pattern


The spout and deflector can be set to create a windrow or for spreading.

For bedding or mulching, remove the spout assembly. This allows the chopped material to discharge directly from the fan. The distance the material is thrown and the coverage may be varied by rotating the fan housing to obtain the desired results. Adding the optional barrel will throw the material farther.


For Bunk Feeding, set the spout in its working position. Adjust the deflector on the end of the spout up or down to help regulate the force of the material leaving the spout. When bunk feeding, raise the spout above the bunk and use the deflector to direct the material downward. This will reduce the force, helping to prevent material from blowing out of the bunk. If material is still blowing out of the bunk, PTO speed may be decreased.



**Figure 3.8**  
Spout, deflector and fan housing



To create windrows set the spout and deflector as follows; with the spout latched in the working position, the deflector can be raised and the fan housing rotated to place the material in a row as desired.



### 3.4.2 Changing length of cut

Using conveyor speed and slug bar settings to determine material size will reduce the horsepower requirements and increase flail life. If a greater size reduction is required, then add a smaller screen.

Using a screen will produce a relatively small material size, but will require more horsepower, lower production (tons/hour), and result in greater flail and screen wear.

### 3.4.3 Changing screens

Using a screen with a smaller hole will produce a finer cut.

Where a coarse cut is desired, use a screen with a larger hole.

**To change screens, perform the following steps:**


1. Open the access door on side of machine
2. Remove 8 bolts
3. Slide screen out
4. Clean screen track
5. Insert new screen
6. Replace bolts, and access door

### 3.4.4 Adjusting the bale conveyor speed

Moving the lever counterclockwise will slow the conveyor, and make a finer product.. Moving the lever clockwise will speed up the conveyor and make a coarser product.


For tractors with PFC type hydraulic systems:

This valve should be set in the full open position. Conveyor speed can be controlled directly from the tractor controls.



bale conveyor speed  
control valve






### 3.4.5 Changing the slug bar settings

Figure 3.9  
Location of the slug  
bar ratchet

auger and screen access  
panel and shield latch pin

auger and screen  
access panel and shield  
(open position)

slug bar ratchet



Exposing less flail will create a finer cut, while exposing more flail will create a coarser cut.

This is accomplished by adjusting the slug bar ratchet.

## 3.5 Road transport

### 3.5.1 Preparing the BALEBUSTER for transport

To prepare the machine for transport, perform the following steps:

1. Remove loader tines, and store them in the bale chamber or in the transporting vehicle. Save the bolts for later use.
2. Put loader frame in fully up position
3. Push up on links attaching rack to frame, push rack into transport position
4. Check condition of tires
5. Check condition of SMV sign, warning lights, safety chain, as required by local regulations.
6. Place loader wing in transport position.


Folding loader wing in  
transport position

loader tine



rack

loader transport pin in  
transport position



### **3.5.2 Changing Back To Operate**

**To prepare the machine for operation, perform the following steps:**

1. To prevent serious personal injury enforce and follow the safety precautions contained in this manual
2. Hook up to tractor.
3. Lower loader frame.
4. Return rack to working position

## **3.6 Storage**


### **3.6.1 Preparing the machine for storage**

This machine is designed to fold for ease of transportation and storage. The rack assembly folds inside of bale chamber.

**To prepare the BALEBUSTER for storage, perform the following steps:**

1. Shutdown the BALEBUSTER using the normal shutdown procedure.
2. Clean all mud, dirt, grease and other foreign material from the exterior of the machine. Cut all twine off from around the rotor, auger, and fan. Wash the complete machine. If washing the BALEBUSTER with a high pressure washer, keep the nozzle away from the sealed bearings. Repaint places where bare metal is exposed - this will inhibit rusting.
3. Place the jackstands in the down and in locked position. Block the rear axle up taking the weight off the tires, but do not deflate tires. If possible, store the machine in a dry, protected place. If it is necessary to store the machine outside, cover it with waterproof canvas, plastic, or other suitable protective material.
4. Coat exposed cylinder lift rod with grease. Oil chains on conveyor. Lubricate thoroughly according to lubrication instructions. Repack wheel bearings.
6. Check the machine for any worn or broken parts.


By ordering parts now, you will avoid delays when it is time to remove the machine from storage. When ordering parts always specify machine serial number and the part number of the replacement part. Part numbers can be found in the parts section of this manual.



### **3.6.2 Removing the machine from storage**

To remove the **BALEBUSTER** from storage, perform the following steps:

1. Remove all protective coverings.
2. Remove blocking from under the machine
3. Lubricate machine in accordance with lubrication instructions found in this manual.
4. Follow pre-starting inspection instructions.



## Section 4: General maintenance



**IMPORTANT:** Before performing any service or maintenance on your BALEBUSTER, review the safety guidelines for performing service and maintenance in section 1.6 “Safety review” under the heading “**WHEN PERFORMING SERVICE AND MAINTENANCE**”.

### 4.1 Lubrication

**LUBRICATION INSTRUCTIONS:** The operator should make a check of all grease fittings in the unit before beginning to operate it to become familiar with their location and the correct service schedule.



**WARNING:** Use normal shut-down procedure (section 3.3.4) before lubricating machine.

Use only a high quality, multi-purpose grease when lubricating the unit. Make sure all fittings and the nozzle of the grease applicator are clean before applying the grease. If any grease fittings are missing, replace them immediately.


#### 4.1.1 LUBRICATION POINTS

The following grease points will require a ten (10) hour service interval.

- Auger bearings – 2 places see figure 4.1
- Fan housing – 2 places see figure 4.2
- Fan pivot – 1 place see figure 4.2
- P.T.O. Universal joints -2 places see figure 4.3
- Telescoping shaft – 1 place
- Driveline supports – 2 places see figure 4.3
- Loader – 5 places see figure 4.4
- Conveyor – 2 places see figure 4.5
- Rotor bearings – 2 places see figure 4.6

The following grease points will require a forty (40) hour service interval.

- Hitch – 1 place see figure 4.3
- Fan overrunning clutch – 2 places see figure 4.2




To insure the best possible performance, all indicated locations should be greased as often as every five (5) hours under severe conditions. All grease points should be greased at equal intervals.

For the PTO shaft:

- As many as seven (7) pumps of grease are required to purge all cross and bearing grease points with fresh grease.
- Telescoping members require enough grease to maintain a smooth sliding action. When telescoping members become contaminated with dirty grease, they should be inspected and cleaned to insure smooth operation.
- Shield components should be inspected to insure all components are in working condition or are replaced if damaged. A properly maintained shield will inhibit dirt from contaminating telescoping members.

**Figure 4.1**  
**Lubrication points for**  
**auger bearings**




**Auger bearing  
lubrication point**




**Auger bearing  
lubrication point**






**Figure 4.2**  
Lubrication points for  
fan pivot, front, rear fan  
housing & fan overrunning  
clutch




Fan pivot  
lubrication point (1)


Front fan housing  
lubrication point (1)



Rear fan housing  
lubrication point



Fan overrunning clutch  
lubrication points (2)





**Figure 4.3**  
**P.T.O., driveline supports,**  
**and hitch lubrication points**


P.T.O. universal joint  
lubrication point



Hitch pivot  
lubrication point

Driveline support bearings  
lubrication points





**Figure 4.4**  
**Lubrication points for**  
**loader**

**Left lower loader pivot**  
**lubrication point**



**Right lower loader pivot**  
**lubrication point**



**Center upper**  
**loader pivot**  
**lubrication point**




**Right upper**  
**loader pivot**  
**lubrication point**




**Left upper loader pivot**  
**lubrication point**






**Figure 4.5**  
Lubrication points for  
conveyor

Rear conveyor  
lubrication point



Front conveyor  
lubrication point







**Figure 4.6**  
**Lubrication points for rotor**



**Rotor  
lubrication point**



**Rotor  
lubrication point**



## 4.2     **Axle, wheels, tires**

Repack wheel bearings annually.

## 4.3     **Conveyor chain tension**

See section 3.3.7 for instructions on how to adjust.


## 4.4   **Belt Bushing Torque Settings**

<u>Location</u>	<u>ft/lbs.   m/kg</u>	
PTO shaft	83	11.5
Fan/Clutch	67	9.3
Rotor/Front	67	9.3
Rotor/Rear	30	4.1
Auger	30	4.1
Fan/Shaft	36	5.0

## 4.5     **General appearance**


Clean all mud, dirt, grease and other foreign material from the exterior of the machine. Cut all twine off from around the rotor, auger, and fan. Wash the entire machine. If washing the BALEBUSTER with a high pressure washer, keep the nozzle away from the sealed bearings. Repaint places where bare metal is exposed. - this will inhibit rusting.





## Section 5: Troubleshooting

PROBLEM	CAUSE	REMEDY
1. No Capacity	1. Bale turning too slow.	1. Open conveyor speed control valve.
2. Bale Does Not Turn	1. Bale lodged in feeder.	1. Reverse rotation of slat conveyor
3. Excessive Vibration	1. Broken Flail. 2. Defective cylinder bearing. 3. Misaligned or worn PTO 4. Build up of twine on rotor, auger, or fan. 5. Bent rotor, auger, or fan.	1. Replace Flail. 2. Replace Bearing. 3. Replace worn part or complete PTO. 4. Remove all twine from rotor, auger, and fan. 5. Replace as necessary
4. Machine Will Not Lift Bale	1. Tractor hydraulic pressure too low. 2. Hydraulic oil leaking by piston in cylinder.	1. Check pressure. 2. Repair or replace hydraulic cylinder
5. Forage Too Coarse	1. Conveyor speed too fast. 2. Slug bar set too low. 3. Screen removed or screen too coarse.	1. Decrease conveyor speed. 2. Raise slug bar to expose less flail. 3. Add a screen or install a finer screen
6. Forage Too Fine	1. Conveyor speed too slow. 2. Slug bar set too high. 3. Screen installed.	1. Increase conveyor speed. 2. Lower slug bar to expose more flail. 3. Install coarser screen.
7. Fan Plugs	1. Too much material going through fan	1. Slow conveyor speed down. 2. Adjust slug bars so less flail is exposed. 3. Install screen, or install finer screen.
8. Forage Blows Past Bunk When Bunk Feeding	1. Deflector spout too high.	1. Lower Deflector spout.
9. Forage Blows Out of Bunk		1. Reduce PTO speed.
10. Auger Plugs	1. Too much material going through fan.	1. Slow conveyor speed down. 2. Adjust slug bars so less flail is exposed. 3. Install screen, or install finer screen.



## Appendix A: WARRANTY

Duratech Industries International Inc. warrants to the original purchaser for one year from purchase date that this product will be free from defects in material and workmanship when used as intended and under normal maintenance and operating conditions. This warranty is limited to the replacement of any defective part or parts returned to our factory in Jamestown, N.D., within thirty (30) days of failure.

This warranty shall become void if in DuraTech Industries International, Inc.'s., judgment the machine has been subject to misuse, negligence, alterations, damaged by accident or lack of required normal maintenance, or if the product has been used for a purpose for which it was not designed.

All claims for warranty must be made through the dealer which originally sold the product and all warranty adjustments must be made through same.


This warranty does not apply to tires or bearings or any other trade accessories not manufactured by DuraTech Industries International Inc.'s.. Buyer must rely solely on the existing warranty, if any, of these respective manufactures.

DuraTech Industries International Inc., shall **not** be held liable for damages of any kind, direct, contingent, or consequential to property under this warranty. DuraTech Industries International Inc., cannot be held liable for any damages resulting from causes beyond its control. DuraTech Industries International Inc., shall **not** be held liable under this warranty for loss of crops, or rental costs or any expense or loss for labor or supplies.

DuraTech Industries International Inc., reserves the right to make changes in material and/or designs of this product at any time without notice.

All other warranties made with respect to this product, either expressed or implied, are hereby disclaimed by DuraTech Industries International Inc.





# Appendix B: 2574 BALEBUSTER Specifications

## General:


Tractor H.P. required .....	100 HP (76.6 kw) to 155 HP (115.6 kw)
Capacity .....	5-1/2' long x 6-1/2' diameter, 2000 lbs. (1.67 m x 1.98m, 907.2 kg)
Rotor Length .....	78" (1.98 m)
Rotor Diameter(flail tip to flail tip) .....	25-1/2" (64.8 cm)
Flails - Swinging / Heavy Spring Steele .....	40
Wheel - Taper Roller Bearings .....	
PTO .....	1000 RPM
Dual Hydraulics (single hydraulic system optional) .....	1500 PSI (105.6 kgf/cm <sup>2</sup> )
Tire Size .....	See Appendix C
Cylinder .....	4-1/2" x 24" (11.43 cm x 60.96 cm) Double Acting

## Transport Position:

Height .....	129" (3.26 m)
Width .....	101" (2.57 m)
Length.....	198" (5.02 m)
Weight .....	6325 Lbs. (2,868.97 kg)


## Working Positions:

Working Position 1 Bale Height.....	129" (3.26 m)
Length.....	198" (5.02 m)
Width .....	123" (3.12 m)
Working Position 2 Bales Height .....	129" (3.26 m)
Length.....	271" (6.88 m)
Width .....	123" (3.12 m)



# Appendix C: Options

- Hydraulic fan housing rotation, allows fan housing to be rotated “on the go”, requires 1 hydraulic valve and set of outlets on tractor
- Hydraulic fan discharge spout rotation, allows discharge spout to be rotated on the go, also requires 1 hydraulic valve and set of outlets on tractor.
- Cannon discharge spout, allows for spreading material over greater distance.
- Screens available are:
  - 4-1/4” x 10-1/2”
  - 6-1/2” x 10-1/2”
- “No Loader” If machine is to be loaded by front end loader or the like, the loader may not be needed.
- Manual fan housing rotation
- Curved spout - 80 degrees
- Slugbars - Hydraulic
- Tires:
  - 31 X 10.5 X 15 “C” HWY - Standard
  - 14L X 16.1 8 PLY FLOT IMP - Option
- 2nd Axle with highway tires
- Shredder extension kit
- Containment kit



## Appendix D: Required For Operation




**WARNING: Do not operate the BALEBUSTER unless the tractor complies with the following requirements:**


1. Horsepower - 80 HP minimum. 1000 rpm, 1-3/8" PTO shaft.
2. Rollover protective structure and seat-belts.
3. Hydraulic system - 8 gallons per minute (30 liters per minute) minimum, 1500 Psi minimum (105 bar).
4. Two double acting control valves.
5. The tractor must be of equal or greater weight than the BALEBUSTER and bale to assure adequate braking and steering control.
6. Counterbalance weight - It may be necessary to add weight to the front end of your tractor to maintain adequate tractor stability and control. At least 20% of the total weight must remain on the front axle.
7. Tractor os setup according to section 3.3.1 "tractor setup"
8. 12V D.C. Auxiliary power socket on tractor.

### Three Pin Socket

An auxiliary power connection is provided inside the operators compartment for connecting monitors, implement controllers, C.B. radios and other 12-volt equipment.


The three pin outlet is located on the right hand side to the rear of the seat. The outlet has a ground terminal and two 12-volt power terminals. One power terminal is through the key switch and the other is direct power






## Appendix E: 2574 BALEBUSTER SHIPPING LIST

PART#	QUANTITY	DESCRIPTION
4800471	2	BOLT\HEX\1X7\NC
4900127	2	NUT\TPLCK\1\NC
8101033	1	TINE\LEFT
8101075	1	TINE\RIGHT
5701167	1	JOYSTICK\CNTRBX\4-FNCTN\W-HR







# ***2574™ BALEBUSTER***

## ***Parts Reference***



DuraTech Industries International Inc. (DuraTech Industries) has made every effort to assure that this manual completely and accurately describes the operation and maintenance of the 2574 BALEBUSTER™ as of the date of publication. DuraTech Industries reserves the right to make updates to the machine from time to time. Even in the event of such updates, you should still find this manual to be appropriate for the safe operation and maintenance of your unit.

This manual, as well as materials provided by component suppliers to DuraTech Industries are all considered to be part of the information package. Every operator is required to read and understand these manuals, and they should be located within easy access for periodic review.




&




are registered trademarks of DuraTech Industries International, Inc. 2574 and BALEBUSTER are trademarks of DuraTech Industries International, Inc. STRAW CANNON® and logo are registered trademarks of Duratech Industries International, Inc.






## 2574 Balebuster Parts Reference

2574 Frame Assembly	1
3600838 PTO	5
3600839 PTO	7
2574 Fan Assembly	9
2574 Fan Assembly-Replacement Fins and Shaft	15
2574 Fan Guard Assembly	17
2574 Drive Assembly	19
2574 Shredder Assembly - Front	23
2574 Shredder Assembly - Shields, Door, Screen	25
2574 Auger Assembly	29
2574 Rotor Assembly	31
2574 Slug Bar Assembly	33
2574 Conveyor Assembly	35
2574 Rack Assembly	39
2574 Loader Assembly	41
2574 Wheel and Bearing Assembly	43
2574 Hydraulic Assembly (for SN thru 0051)	45
2574 Hydraulic Assembly (for SN 0052 and up)	51
3900025 Orbit Motor Assembly	57
4000331-Flow Control Valve	59
4000569-Hydraulic Valve	61
2574 Joystick Control Box	63
2574 Round Taillights - Standard Mounting	65
2574 Rectangular Taillights-Standard Mounting	67
2574 Optional Curved Spout	69
2574 Optional 5-1/2 Ft. Straw Cannon Assembly	71
2574 Optional Spout Hose Bracket	73
2574 Optional Spout Mini-Gun	75
2574 Optional 80 Degree Spout	77
2574 Optional Flotation Tires	79
Optional Axle Extensions	81
2574 Optional 2nd Axle with Highway Tires Only	83
2574 Optional Shredder Extension Assembly	85
2574 Optional Containment Flap Assembly	87
2574 Optional Hydraulic Slug Bar	89
2574 Optional Hydraulic Rack Assembly	91
2574 Decals	93
2574 Decal Locations	95
2574 Decal Locations	96
2574 Decal Locations	97
4000569 Hydraulic Valve Wire Layout	98
2574 Hydraulic Schematic	99
2574 Electrical Schematic	100
2574 Tractor/Implement Wiring Harness	101
5701079 - Shredder Taillight Schematic	102
5701296 - Shredder Rectangular Taillights Wiring Schematic	103








This page intentionally left blank


## 2574 Frame Assembly

Item	Part No.	Name	Remarks	Qty	Uom
1	2600041	Tire\31X10.5X15 Highway Tire		2	EA.
2	2600624	Wheel, 15" x 10 6-Bolt		2	EA.
CA	2600823	WHL\HWY\31X10.5X15\TIRE&RIM	(Includes #1 & #2)	2	EA.
3	2900171	HUB\6-BOLT\STUDS\COMPLETE	See Wheel and Bearing Assembly	2	EA.
4	3800043	FTG\LUB\1/8MPXZRK\SHORT		1	EA.
5	4800056	PIN\HAIR\3/16(#3)		1	EA.
6	4800185	PIN\CLEVIS\1X3		1	EA.
7	4800248	BOLT\HEX\3/4X6		2	EA.
8	4800350	BOLT\HEX\5/8X2-1/4		8	EA.
9	4800562	BOLT\HEX\3/4X5\GR8\NC		1	EA.
10	4800647	BOLT\HEX\1X4\NC		2	EA.
11	4900005	NUT\HEX\5/8\NC		8	EA.
12	4900127	NUT\TPLCK\1\NC		3	EA.
13	4900139	NUT\TPLCK\3/4\GR8\NC		3	EA.
14	5000003	WASH\LOCK\5/8		8	EA.
15	5000014	WASH\FLAT\1		1	EA.
16	5800633	JACK\7000\SDWND\SQ\15"TRVL		1	EA.
17	7501047	HITCH\BASE\#3\PPI\1"PIN		1	EA.
18	7501048	HITCH\CLEVIS\PPI\1"PIN		1	EA.
19	7501069	GRMT\RBBR\2X1.75IDX1/4T		2	EA.
20	8101828	SPNDL\BOLT-ON\HVY_DUTY		2	EA.
21	8101953	MNFRM\2574		1	EA.
22	8101954	HITCH\SWING\2574		1	EA.
23	8101971	BRACE\HITCH\2574		1	EA.
24	8102121	PIN\HITCH\SWING\MNFRM		1	EA.



# 3600838 PTO


Item	Part No.	Name	Remarks	Qty	Uom
CA	3600838	1-3/4" PTO\55E\BALL-SHEAR			EA.
CA	3600880	1-3/8" PTO\55E\BALL-SHEAR			EA.
1	3600820	CROSS & BEARING KIT\55E		2	EA.
2	3600536	YOKE\55\QD\CLR\1-3/4\20SP			EA.
2A	3600535	YOKE ASSY\55W\1-3/8\21-SP			EA.
3	3600900	GUARD\INNER\3600838,3600839			EA.
4	3600902	GUARD\OUTER\3600838			EA.
5	3600876	PTO\HALF\MACHINE	(Includes #1, #2, #4 & #6)		EA.
6	3600878	1-3/4" PTO\HALF\TRACTOR	(Includes #1,#3,#5 & #7)		EA.
6A	3600881	1-3/8" PTO\HALF\TRACTOR	(includes #1,#3,#5 & #7)		EA.
NS	4800326	SCR\SET\AL1/2X1/2\NC		1	EA.
NS	4800323	SCR\SET\AL1/2X1\NC		1	EA.
NS	4800982	3/8X2 GRADE 2 SHEAR BOLT		2	EA.
NS	6200061	KEY\SQ\1/2X2-1/4		1	EA.







# 3600839 PTO

Item	Part No.	Name	Remarks	Qty	Uom
CA	3600839	1-3/4" PTO\55E\CAT6\WWCV			EA.
CA	3600882	1-3/8" PTO\55E\CAT6\WWCV			EA.
1	3600764	CROSS&BRG\CAT6\80DEG\CV		2	EA.
2	3600765	CENTER-HOUSING		1	EA.
3	3600782	YOKE\44E\WWCV\1-3/4\20SP\AL		1	EA.
3A	3600763	YOKE\44E\1-3/8CV-21\CAT6\AL		1	EA.
4	3600901	GUARD\OUTER\3600839		1	EA.
5	3600875	1-3/4" PTO\HALF\TRACTOR	( Includes #1-#5)		EA.
5A	3600883	1-3/8" PTO\HALF\TRACTOR	(Includes #1-#5)		EA.
6	3600820	CROSS & BEARING KIT\55E		1	EA.
7	3600876	PTO\HALF\MACHINE	(Includes #6-#9)		EA.
8	3600900	GUARD\INNER\3600838,3600839		1	EA.
NS	4800326	SCR\SET\AL1/2X1/2\NC		1	EA.
NS	4800323	SCR\SET\AL1/2X1\NC		1	EA.
NS	4800982	3/8X2 GRADE 2 SHEAR BOLT		2	EA.
NS	6200061	KEY\SQ\1/2X2-1/4		1	EA.





This page intentionally left blank

## 2574 Fan Assembly


Item	Part No.	Name	Remarks	Qty	Uom
1	1000129	SPKT\60\B\12\1\1/4KW		1	EA.
2	1100062	CHAIN\60\CL		1	EA.
3	1100063	CHAIN\60\OL		1	EA.
4	1100270	CHAIN\60\77		1	EA.
5	2000080	BRG\CAM\1/2" I.D.X1-1/2" O.D		7	EA.
6	2000311	BRG\FLG\CAST\1-3/4\4BOLT		2	EA.
7	4500529	PL\MNT\FAN		1	EA.
8	4800003	BOLT\HEX\3/8X1		10	EA.
9	4800010	BOLT\HEX\5/8X2		2	EA.
10	4800034	BOLT\HEX\3/8X1-1/2		8	EA.
11	4800068	BOLT\HEX\1/2X3		4	EA.
12	4800082	BOLT\HEX\1/2X1-1/2		6	EA.
13	4800172	PIN\COT\1/8X2		1	EA.
14	4800178	BOLT\HEX\1/2X1-3/4		7	EA.
15	4800196	BOLT\HEX\5/8X2-3/4		2	EA.
16	4800516	BOLT\HEX\3/8X3-3/4\NC		2	EA.
17	4900001	NUT\HEX\1/2\NC		17	EA.
18	4900002	NUT\HEX\3/8\NC		18	EA.
19	4900005	NUT\HEX\5/8\NC		4	EA.
20	4900023	NUT\TPLCK\3/8\NC		2	EA.
21	4900046	NUT\JAM\1/2\NC		7	EA.
22	5000001	WASH\FLAT\3/8		10	EA.
23	5000002	WASH\FLAT\5/8		8	EA.
24	5000003	WASH\LOCK\5/8		4	EA.
25	5000004	WASH\FLAT\1/2		2	EA.
26	5000006	WASH\LOCK\1/2		17	EA.
27	5000019	WASH\LOCK\3/8		18	EA.
28	5000134	WASH\LOCK\TOOTH\INT\1/2		7	EA.
29	8100542	MNT\MTR\ORBIT\FAN		1	EA.
30	8101663	DBLR\MNT\SWVL\FAN		2	EA.
31	8101664	MNT\SWVL\FAN		4	EA.
32	8101665	MNT\PL\FAN\3/4"		1	EA.
33	8101666	MNT\PL\FAN		1	EA.
34	8101695	MNT\PL\FAN		1	EA.
35	8101697	BRACE\FAN\2564		1	EA.
36	8101720	SHT\LINER\FAN		1	EA.
37	8101735	SHIM\MNT\FAN\10GA		1	EA.
38	8101754	SHLD\CHN\RTT\FAN-TRANS		1	EA.



This page intentionally left blank


## 2574 Fan Assembly

Item	Part No.	Name	Remarks	Qty	Uom
39	8101772	LNR\SPT\HSG\FAN		1	EA.
40	8101847	TRANS\FAN		1	EA.
41	8101975	HSG\FAN\REAR		1	EA.
42	8101995	HSG\FAN\W\LINER		1	EA.
43	8101997	FAN\ASSY\REPLCB\FINS-SHAFT		1	EA.
44	8102001	SH\HSG\FAN		1	EA.
45	8102002	CVR\ACT\FAN		1	EA.
46	8102044	MNT\FRONT\FAN\2574		1	EA.
47	8102135	PIN\CYL\FAN\2574		1	EA.



## 2574 Fan Assembly-Replacement Fins and Shaft


Item	Part No.	Name	Remarks	Qty	Uom
1	1400847	BUSH\2517\2-7/16		2	EA.
2	4800628	BOLT\HEX\1/2X1-1/4\GR8\NC		24	EA.
3	4900014	NUT\TPLCK\1/2\NC		24	EA.
4	6200098	KEY\REC\1/2X5/8X2		2	EA.
5	8101836	RTR\FAN\BOLT-ON\FIN\SHAFT		1	EA.
6	8101998	MNT\FIN\REPLACEABLE		6	EA.
7	8102000	SHFT\RTR\FAN	(for SN Thru 0051)	1	EA.
7A	8102166	SHFT\RTR\FAN	(for SN 0052 & Up)	1	EA.
CA	8101997	FAN\ASSY\REPLCB\FINS-SHAFT			EA.





## 2574 Fan Guard Assembly

Item	Part No.	Name	Remarks	Qty	Uom
1	4800054	BOLT\HEX\5/8X3-1/2		1	EA.
2	4800236	BOLT\HEX\5/8X8		1	EA.
3	4800647	BOLT\HEX\1X4\NC		1	EA.
4	4900005	NUT\HEX\5/8\NC		2	EA.
5	4900127	NUT\TPLCK\1\NC		1	EA.
6	5000002	WASH\FLAT\5/8		4	EA.
7	5000003	WASH\LOCK\5/8		2	EA.
8	8102332	BRKT\GUARD\FAN		1	EA.
CA	8102351	KIT\GUARD\FAN\2574			EA.




## 2574 Drive Assembly

Item	Part No.	Name	Remarks	Qty	Uom
1	1400840	SHVE\5V-4\12.5\TB		2	EA.
2	1400841	SHVE\5V-4\15.0\TB		2	EA.
3	1400844	BUSH\A2\2		1	EA.
4	1400845	BUSH\A2\3		1	EA.
5	1400846	BUSH\B3\2		2	EA.
6	1600111	V-BELT\5VX\4\90.0		1	EA.
7	1600112	V-BELT\5VX\4\100.0		1	EA.
8	2000510	BRG\PB\2\2BOLT		3	EA.
9	3600837	CLUTCH\OVERRUNNING\CW	(Thru SN 0051)	1	EA.
9A	3600898	CLUTCH\OVERRUNNING\CW\5-1/4" L	(for SN 0052 and Up)	1	EA.
10	3700830	HOSE\LUB\1\8X16\MPS-MPS		1	EA.
11	3700830	HOSE\LUB\1\8X16\MPS-MPS		1	EA.
12	3800111	FTG\MPXFP\90\ST;EL		1	EA.
13	4800003	BOLT\HEX\3\8X1		4	EA.
14	4800040	BOLT\HEX\7\16X1-1/2		2	EA.
15	4800063	BOLT\HEX\3\4X4		2	EA.
16	4800082	BOLT\HEX\1\2X1-1/2		8	EA.
17	4800098	BOLT\HEX\3\8X1-1/4\NC		13	EA.
18	4800100	BOLT\HEX\5\8X4		4	EA.
19	4800178	BOLT\HEX\1\2X1-3/4		1	EA.
20	4800197	BOLT\HEX\3\8X3-1/2		2	EA.
21	4800468	SCR\RD\SLOT\#10-24X1/2\NC		4	EA.
22	4800643	BOLT\HEX\5\16X3/4		2	EA.
23	4900001	NUT\HEX\1\2\NC		9	EA.
24	4900002	NUT\HEX\3\8\NC		16	EA.
25	4900003	NUT\HEX\5\16\NC		2	EA.
26	4900005	NUT\HEX\5\8\NC		4	EA.
27	4900023	NUT\TPLCK\3\8\NC		2	EA.
28	4900025	NUT\HEX\7\16\NC		2	EA.
29	4900072	NUT\HEX\#10\NC		4	EA.
30	4900139	NUT\TPLCK\3\4\GR8\NC		2	EA.
31	5000001	WASH\FLAT\3/8		30	EA.
32	5000002	WASH\FLAT\5/8		8	EA.
33	5000003	WASH\LOCK\5/8		4	EA.
34	5000004	WASH\FLAT\1/2		17	EA.
35	5000006	WASH\LOCK\1/2		9	EA.
36	5000015	WASH\LOCK\7/16		2	EA.
37	5000019	WASH\LOCK\3/8		17	EA.

This page intentionally left blank

## 2574 Drive Assembly


Item	Part No.	Name	Remarks	Qty	Uom
38	5000022	WASH\LOCK\5/16		2	EA.
39	5000071	WASH\LOCK;EXT\STAR\#10		4	EA.
40	6200021	KEY\SQ\3/8X1-1/2\HARDEND	(Thru SN 0051)	1	EA.
40A	6200020	KEY\SQ\3/8X2-1/4\HARDEND	(for SN 0052 and Up)	1	EA.
41	6200061	KEY\SQ\1/2X2-1/4		4	EA.
42	7500170	HOSE MINDER		1	EA.
43	7501616	IDLER\BELT\STEEL\3.5"WIDE		2	EA.
44	7501617	TNSR\BELT\SE38		2	EA.
45	7501660	LATCH\RBBR\8"W-STD-CATCH		2	EA.
46	7501660	LATCH\RBBR\8"W-STD-CATCH		2	EA.
47	7501660	LATCH\RBBR\8"W-STD-CATCH		2	EA.
48	8101984	SHLD\DRV\MDDL\FRNT\2574		1	EA.
49	8101985	SHLD\DRV\TR\		1	EA.
50	8101986	SHLD\DRV\FAN		1	EA.
51	8101996	SHFT\DRV\BLT		1	EA.
52	8102116	MNT\TNSR\BELT		2	EA.
53	8102122	SHLD\DRV\FAN\2574		1	EA.
54	8102125	MNT\LINE\GREASE\		2	EA.
55	8102136	KEY\STEP\CLUTCH\FAN\2574		1	EA.
56	8102137	DISK\RETAINER\FAN\2574		1	EA.
57	8102139	MNT\SHLD\DRV\FAN		1	EA.
58	8102157	HINGE\SHLD\2574		2	EA.
59	8102154	WRENCH\OPEN END\2-1/8	(Used on Auger Drive)	1	EA.
60	8102155	WRENCH\OPEN END\2-3/4	(Used on Fan)	1	EA.
61	7501693	SEAL\OPNCEL\FOAM\3/4 X3/8		2	FT.





**2574 Shredder Assembly - Front**

Item	Part No.	Name	Remarks	Qty	Uom
1	3701578	HOSE\LUB\1\8X33\MPS-MPS		1	EA.
2	3800043	FTG\LUB\1\8MPXZRK\SHORT		1	EA.
3	3800111	FTG\MPXFP\90\ST;EL		1	EA.
4	4800003	BOLT\HEX\3\8X1		8	EA.
5	4800033	BOLT\HEX\3\4X2		4	EA.
6	4800085	BOLT\HEX\1\2X1		1	EA.
7	4800098	BOLT\HEX\3\8X1-1\4\NC		1	EA.
8	4800107	PIN\HAIR\1\8(#9)		1	EA.
9	4800468	SCR\RD\SLOT\#10-24X1\2\NC		2	EA.
10	4800643	BOLT\HEX\5\16X3\4		1	EA.
11	4900001	NUT\HEX\1\2\NC		1	EA.
12	4900002	NUT\HEX\3\8\NC		7	EA.
13	4900003	NUT\HEX\5\16\NC		1	EA.
14	4900004	NUT\HEX\3\4\NC		4	EA.
15	4900023	NUT\TPLCK\3\8\NC		3	EA.
16	4900072	NUT\HEX\#10\NC		2	EA.
17	5000005	WASH\FLAT\3\4		8	EA.
18	5000006	WASH\LOCK\1\2		1	EA.
19	5000012	WASH\LOCK\3\4		4	EA.
20	5000019	WASH\LOCK\3\8		7	EA.
21	5000022	WASH\LOCK\5\16		1	EA.
22	5000071	WASH\LOCK;EXT\STAR\#10		2	EA.
23	7501660	LATCH\RBBR\8\W-STD-CATCH		1	EA.
24	7501660	LATCH\RBBR\8\W-STD-CATCH		1	EA.
25	7501660	LATCH\RBBR\8\W-STD-CATCH		1	EA.
26	8101282	DOOR\AUGER EX\2564		1	EA.
27	8101748	BRKT\STRG\JACK		1	EA.
28	8101973	FRM\SHREDDER\2574		1	EA.
29	8101974	AUGER\EXT		1	EA.
30	8102124	MNT\LINE\GREASE		1	EA.
31	8102133	HANDLE\RACK\2574		1	EA.
32	8102134	LEG\TOOL\RACK		1	EA.



**2574 Shredder Assembly - Shields, Door, Screen**

Item	Part No.	Name	Remarks	Qty	Uom
1	3700770	HOSE\LUB\1/8X8-1/2\MPS-MPS		1	EA.
2	3701487	HOSE\LUB\1/8X27.25\MPS-MPS		1	EA.
3	3800043	FTG\LUB\1/8MPXZRK\SHORT		1	EA.
4	3800135	FTG\LUB\1/8MPXZRK\SHORT		1	EA.
5	3800244	FTG\1/8MPX1/8FP\45		1	EA.
6	4800003	BOLT\HEX\3/8X1		11	EA.
7	4800013	BOLT\HEX\5/16X1		2	EA.
8	4800018	BOLT\HEX\1/2X1-1/4		4	EA.
9	4800034	BOLT\HEX\3/8X1-1/2		1	EA.
10	4800082	BOLT\HEX\1/2X1-1/2		12	EA.
11	4800098	BOLT\HEX\3/8X1-1/4\NC		2	EA.
12	4800198	BOLT\HEX\5/16X3-3/4		2	EA.
13	4800468	SCR\RD\SLOT\#10-24X1/2\NC		4	EA.
14	4800643	BOLT\HEX\5/16X3/4		2	EA.
15	4900001	NUT\HEX\1/2\NC		12	EA.
16	4900002	NUT\HEX\3/8\NC		14	EA.
17	4900003	NUT\HEX\5/16\NC		2	EA.
18	4900014	NUT\TPLCK\1/2\NC		4	EA.
19	4900023	NUT\TPLCK\3/8\NC		1	EA.
20	4900072	NUT\HEX\#10\NC		4	EA.
21	4900099	NUT\TPLCK\5/16\GR8\NC		2	EA.
22	5000001	WASH\FLAT\3/8		16	EA.
23	5000004	WASH\FLAT\1/2		10	EA.
24	5000006	WASH\LOCK\1/2		12	EA.
25	5000019	WASH\LOCK\3/8		14	EA.
26	5000022	WASH\LOCK\5/16		2	EA.
27	5000071	WASH\LOCK;EXT\STAR\#10		4	EA.
29	7500743	GRMT\RBBR\1-3/8X1IDX1/4T		2	EA.
30	7501628	CNSTRS\MANUAL\12X3.5		1	EA.
31	7501660	LATCH\RBBR\8W-STD-CATCH		2	EA.
32	7501660	LATCH\RBBR\8W-STD-CATCH		2	EA.
33	7501660	LATCH\RBBR\8W-STD-CATCH		2	EA.
34	8100036	MNT\MTR\HYD		1	EA.
35	8101281	DOOR\SHREADER\2564		1	EA.
36	8101678	LATCH\DOOR		1	EA.
37	8102008	SHLD\AUGER\2574		1	EA.
38	8102027	SHLD\REAR\SHRDR\FLL		1	EA.
39	8102123	MNT\LINE\GREASE		1	EA.

This page intentionally left blank

## 2574 Shredder Assembly - Shields, Door, Screen


Item	Part No.	Name	Remarks	Qty	Uom
40	8102124	MNT\LINE\GREASE		2	EA.
41	8102360	MNT\SCRN\BTM\SHREDDER		1	EA.
	PNNA	Screens			EA.
28	5400128	SCRN\4-1/4X10-1/2		1	EA.
28	5400129	SCRN\6-1/2X10-1/2		1	EA.
28	5400135	SCRN\2HL\ROUND		1	EA.
28	5400136	SCRN\3HL\ROUND		1	EA.
28	5400137	SCRN\4HL\ROUND		1	EA.






## 2574 Auger Assembly

Item	Part No.	Name	Remarks	Qty	Uom
1	1400578	BUSH\QD\SF\2		1	EA.
2	1400582	BUSH\Q1\1-1/2		1	EA.
3	1400842	SHVE\5V-3\7.4\SF		1	EA.
4	1400850	SHVE\5V-3\11.8\SF		1	EA.
5	1600117	V-BELT\5VX\3\75.0		1	EA.
6	2000302	BRG\FLG\CAST\1-1/4\3BOLT		1	EA.
7	2000308	BRG\FLG\CAST\1-1/2\2BOLT		1	EA.
8	3800244	FTG\1/8MPX\1/8FP\45		1	EA.
9	4800003	BOLT\HEX\3/8X1		6	EA.
10	4800018	BOLT\HEX\1/2X1-1/4		4	EA.
11	4800034	BOLT\HEX\3/8X1-1/2		1	EA.
12	4800082	BOLT\HEX\1/2X1-1/2		2	EA.
13	4800188	BOLT\HEX\1/2X4		1	EA.
14	4900001	NUT\HEX\1/2\NC		6	EA.
15	4900002	NUT\HEX\3/8\NC		7	EA.
16	4900014	NUT\TPLCK\1/2\NC		1	EA.
17	4900076	NUT\FLG\SERR\3/8\NC		3	EA.
18	5000004	WASH\FLAT\1/2		2	EA.
19	5000006	WASH\LOCK\1/2		6	EA.
20	5000019	WASH\LOCK\3/8		7	EA.
21	6200026	KEY\SQ\3/8X3		1	EA.
22	6200061	KEY\SQ\1/2X2-1/4		1	EA.
23	7501601	TNSR\BELT\SE27		1	EA.
24	7501602	IDLER\BELT\STEEL\3.5"WIDE		1	EA.
25	8101979	AUGER		1	EA.
26	8102063	MNT\TNSR\BELT		1	EA.
27	8102132	HSG\END\AUGER-PAN		1	EA.
28	8102344	MNT\BRG\AUGER\W-TWINEGUARD		1	EA.
29	8102363	BOLT\SP\CRG\3/8X1-3/4\NC		3	EA.




## 2574 Rotor Assembly

Item	Part No.	Name	Remarks	Qty	Uom
1	2000510	BRG\PB\2\2BOLT		2	EA.
2	4800018	BOLT\HEX\1/2X1-1/4		4	EA.
3	4800079	BOLT\HEX\5/8X2-1/2		4	EA.
4	4800598	BOLT\HEX\5/8X4\NF\GR8		40	EA.
5	4900001	NUT\HEX\1/2\NC		4	EA.
6	4900005	NUT\HEX\5/8\NC		4	EA.
7	4900179	NUT\TPLCK\RTR\5/8\NF\GR9		40	EA.
8	5000002	WASH\FLAT\5/8		8	EA.
9	5000003	WASH\LOCK\5/8		4	EA.
10	5000006	WASH\LOCK\1/2		4	EA.
11	5200012	FLAIL\BB\8		40	EA.
12	7500223	BUSH\FLAIL\1-1/4X.687x2-1/8L		40	EA.
13	7501050	PLATE\SICKLE		2	EA.
14	8101462	SHM\16GA\BRG\RTR		2	EA.
15	8101631	SHM\10GA\BRG\RTR		2	EA.
16	8101989	RTR\FLAIL\2"SHFT\HVY		1	EA.
17	8102138	BRKT\BRG\2"\REAR\RTR		1	EA.



## 2574 Slug Bar Assembly

Item	Part No.	Name	Remarks	Qty	Uom
1	2000813	CLLR\SHFT\1-1/2\SET		1	EA.
2	4800082	BOLT\HEX\1/2X1-1/2		4	EA.
3	4800143	SCR\SET\ALN\3/8X3/8\NC		2	EA.
4	4800456	PIN\RLLD\3/16X1-1/8		1	EA.
5	4800483	BOLT\CRG\5/8X2\NC		9	EA.
6	4900001	NUT\HEX\1/2\NC		4	EA.
7	4900012	NUT\TPLCK\5/8\NC		9	EA.
8	5000004	WASH\FLAT\1/2		4	EA.
9	5000006	WASH\LOCK\1/2		4	EA.
10	5000008	WASH\MACH\1-1/2IDX10GA\NR		1	EA.
11	6100031	SPRING\COMP\0.072W\25/32OD		1	EA.
12	6200021	KEY\SQ\3/8X1-1/2\HARDEND		1	EA.
13	7500736	GRIP\HAND\1X4-1/2\FLG		1	EA.
14	8100765	SHFT\ADJ\SLUGBAR		1	EA.
15	8101038	BRKT\INDEX\SLUGBAR		1	EA.
16	8101039	BRKT\BRG\SLUGBAR		1	EA.
17	8101050	BRKT\HANDLE\INDEX\SLUGBAR		1	EA.
18	8101278	BAR\SLUG\ADJ		9	EA.
19	8101306	BRKT\MNT\HANDLE\SLUGBAR		1	EA.






## 2574 Conveyor Assembly

Item	Part No.	Name	Remarks	Qty	Uom
1	1000233	SPKT\60\B\12\1\1\4KW		1	EA.
2	1000306	SPKT\662\7\1-1\4\IDLER		3	EA.
3	1000307	SPKT\662\7\1-1\4\1\4KW\DRV		3	EA.
4	1000308	SPKT\60\B\12\1-1\4\1\4KW		1	EA.
5	1100240	CHAIN\60\12\CPLNG\W-CL		1	EA.
6	1100312	CHAIN\620CA\53\W\ATTCH		3	EA.
7	1100319	CHAIN\620CA\CL\HITACHI		3	EA.
8	2000333	BRG\FLG\CAST\1-1\4\3-BOLT		2	EA.
9	2000805	CLLR\SHFT\1-1\4\W\SET		11	EA.
10	2000827	CLLR\SHFT\1-1\4\TWO-PIECE		1	EA.
11	3701601	HOSE\LUB\1\8X39\MPS-MPS		1	EA.
12	3701601	HOSE\LUB\1\8X39\MPS-MPS		1	EA.
13	3800043	FTG\LUB\1\8MPXZRK\SHORT		2	EA.
14	3800895	FTG\1\8FP\CPLG\ANCHOR\5\8NF		2	EA.
15	3801009	FTG\LUB\1\4-28MX1\8NPTF\45\ELB		2	EA.
16	3900025	MOTOR\HYD\17.9\HAMNT\7\8FOR\1SHFT		1	EA.
17	4800034	BOLT\HEX\3\8X1-1\2		6	EA.
18	4800082	BOLT\HEX\1\2X1-1\2		6	EA.
19	4800098	BOLT\HEX\3\8X1-1\4\NC		6	EA.
20	4800227	SCR\SET\ALN\5\16X5\16\NC		6	EA.
21	4800307	SCR\SET\SQ\3\8X1\NC		1	EA.
22	4800393	BOLT\HEX\5\16X7\8\GR8		54	EA.
23	4900001	NUT\HEX\1\2\NC		6	EA.
24	4900002	NUT\HEX\3\8\NC		8	EA.
25	4900004	NUT\HEX\3\4\NC		1	EA.
26	4900026	NUT\JAM\3\8\NC		1	EA.
27	4900099	NUT\TPLCK\5\16\GR8\NC		54	EA.
28	4900104	NUT\JAM\3\4\NC		6	EA.
29	4900109	NUT\FLG\TPLCK\3\8\NC		6	EA.
30	5000001	WASH\FLAT\3\8		8	EA.
31	5000004	WASH\FLAT\1\2		12	EA.
32	5000006	WASH\LOCK\1\2		6	EA.
33	5000007	WASH\1-1\4\MACH\BUSH		2	EA.
34	5000019	WASH\LOCK\3\8		4	EA.
35	5000041	WASH\3\4\ID\1-1\8OD\16GA		2	EA.
36	6200005	KEY\SQ\1\4X1-1\2		4	EA,
37	6200011	KEY\WDF\1\4X1		1	EA.
38	7501589	BRG\NYLTRN\1-1\4\HALF\2SQ-OD		2	EA.

This page intentionally left blank


## 2574 Conveyor Assembly

Item	Part No.	Name	Remarks	Qty	Uom
39	8101048	MNT\CNVYR\3\BRK		2	EA.
40	8101052	PL\RUB\CHAIN\CNVYR		2	EA.
41	8101053	PLT\SLAT\2640		9	EA.
42	8101852	MNT\BRG\SPLIT\CNVYR		1	EA.
43	8102030	SHFT\IDLER\1-1/4\CNVYR		1	EA.
44	8102031	SHFT\DRIVE\1-1/4\CNVYR		1	EA.
45	8102032	BRKT\SHAFT\IDLER\CNVYR		1	EA.
46	8102033	BRKT\SHAFT\IDLER\NO-TAP\1-1/4		1	EA.
47	8102034	SUP\SHFT\IDLER\CNVYR\1-1/4		1	EA.
48	8102035	GUARD\TWINE\CNVYR\3HL		2	EA.
49	8102038	FRM\CNVYR\FLATBOTTOM\1-1/4"		1	EA.
CA	8102043	CNVYR\ASSY\1-1/4\SHFT\LH\COMPLETE			EA.



## 2574 Rack Assembly


Item	Part No.	Name	Remarks	Qty	Uom
1	4800351	BOLT\HEX\1/2X2-3/4		8	EA.
2	4900014	NUT\TPLCK\1/2\NC		8	EA.
3	8101090	BRKT\STRAP\RACK\W-STOP\FRONT		1	EA.
4	8101091	BRKT\STRAP\RACK\W-STOP\REAR		1	EA.
5	8101092	BRKT\STRAP\RACK\FRONT		1	EA.
6	8101093	BRKT\STRAP\RACK\REAR		1	EA.
7	8102028	RACK\2574		1	EA.






## 2574 Loader Assembly



Item	Part No.	Name	Remarks	Qty	Uom
1	3800082	FTG\LUB\1\4NFXZERK\ADAPT		5	EA.
2	4800003	BOLT\HEX\3\8X1		2	EA.
3	4800056	PIN\HAIR\3\16(#3)		2	EA.
4	4800471	BOLT\HEX\1X7\NC		2	EA.
5	4800609	PIN\LYNCH\3\8X1-3\4\W/_U_WIRE;KEEPER		2	EA.
6	4800633	BOLT\HEX\1X5-1\2\NC\GR5\PLT		1	EA.
7	4900023	NUT\TPLCK\3\8\NC		2	EA.
8	4900127	NUT\TPLCK\1\NC		8	EA.
9	8100794	PIN\LOCK\TRANSPORT		2	EA.
10	8101033	TINE\SQ\LEFTHAND		1	EA.
11	8101075	TINE\SQ\RIGHTHAND		1	EA.
12	8101311	BOLT\HEX\1X5-1\2\GREASE		1	EA.
13	8101312	BOLT\HEX\1X6-1\2\GREASE		4	EA.
14	8101352	BOLT\HEX\1X6\GREASE		2	EA.
15	8101513	FRM\LOADER\LOWER\		1	EA.
16	8101992	FRAME\LOADER\UPPER		1	EA.
17	8101993	WING\FOLDING		1	EA.
CA	8102011	LDR\ASSY\2574			EA.





## 2574 Wheel and Bearing Assembly

Item	Part No.	Name	Remarks	Qty	Uom
1	2900024	CONE\BRG\OUTER\25877		1	EA.
2	2900029	CONE INNER/WHEL HUB\25590		1	EA.
3	2900083	NUT\WHL\9/16-18\UNF		6	EA.
4	2900164	BRG\CUP\INNER\875		1	EA.
5	2900165	BRG\CUP\OUTER\875		1	EA.
6	2900168	CAP\DUST\875		1	EA.
7	2900169	SEAL\GREASE\875 *VERIFY* O.D. MUST BE 3-3/8, for O.D. 3-5/8 order 2900030	VERIFY O.D. MUST BE 3-3/8, for 3-5/8 order 2900030	1	EA.
8	2900172	STUD\WHL\9/16-18X2-1/8\GR5\P151403		6	EA.
9	4800044	PIN\COT\5/32X1-1/2		1	EA.
10	4900054	NUT\CASTLE\7/8\NF		1	EA.
11	5000055	WASH\SPNDL\7/8 FLAT		1	EA.
CA	2900171	HUB\6-BOLT\STUDS\COMPLETE			EA.










**2574 Hydraulic Assembly (for SN thru 0051)**

Item	Part No.	Name	Remarks	Qty	Uom
1	3800328	FTG\7/8MORX3/4MJIC\ADPT		1	EA.
2	3800453	FTG\3/4MORX9/16MJIC\90		4	EA.
3	3800477	FTG\3/4MORX3/4MJIC\ST		3	EA.
4	3800483	FTG\3/4MORX3/4MJICX3/4MJIC\RUN;TEE		1	EA.
5	3800490	FTG\3/4MOR\PLUG\HEX		2	EA.
6	3800530	FTG\3/4MORX9/16MJIC\ST		2	EA.
7	3800537	FTG\3/4MORX3/4MJIC\90		1	EA.
8	3800538	FTG\7/8MORX9/16MJIC\90		2	EA.
9	3800645	FTG\9/16MJICX9/16+FJIC\90\SW		2	EA.
10	3800683	FTG\3/4MOR\ORFICE\0.0490"		2	EA.
11	3800694	FTG\3/4FOR\QUICK;CPLR\FEMALE		4	EA.
12	3801014	FTG\9/16MJICX9/16FJIC\ORF-CK		2	EA.
13	3900025	MOTOR\HYD\17.9\HAMNT\7/8FOR\1SHFT		2	EA.
14	4000234	VALVE\RELIEF\CROSS\RC13BB		1	EA.
15	4000288	FTG\7/8MORX7/8MJIC\ST\CHCK		1	EA.
16	4000331	VALVE\FLW-CRTL\#8FOR		1	EA.
17	4000569	VL\HYD\BRAND\4-BANK\00277		1	EA.
18	4100224	CYL\HYD\2-1/2X16\1-1/2ROD\3/4OR\RED		1	EA.
19	4100273	CYL\HYD\4-1/2X24\1-3/4 -CANADIAN TOOL & DIE		1	EA.
20	3701562	HOSE\HYD\1/4X111\9/16FJICX9/16FJIC	(FAN CYL ROD END TO AUX VALVE)	1	EA.
21	3701563	HOSE\HYD\1/2X44\3/4MORSX3/4FJIC90	(AUX VALVE TO RELIEF VALVE)	1	EA.
22	3701563	HOSE\HYD\1/2X44\3/4MORSX3/4FJIC90	(AUX VALVE TO RELIEF VALVE)	1	EA.
23	3701619	HOSE\HYD\1/2X150\3/4FJICX3/4MOR	(FLOW CONTROL TO TRACTOR)	1	EA.
24	3701619	HOSE\HYD\1/2X150\3/4FJICX3/4MOR	(FLOW CONTROL TO TRACTOR)	1	EA.
25	3700747	HOSE\HYD\1/4X126\9/16FJICX9/16FJIC	(FAN ORBIT MOTOR TO AUX VALVE)	1	EA.
26	3700747	HOSE\HYD\1/4X126\9/16FJICX9/16FJIC	(FAN ORBIT MOTOR TO AUX VALVE)	1	EA.
27	3700748	HOSE\HYD\1/2X162\3/4MORSX3/4FJIC90	(AUX VALVE TO TRACTOR)	1	EA.
28	3700749	HOSE\HYD\1/2X162\3/4MORSX7/8FJIC90	(AUX VALVE TO TRACTOR)	1	EA.
29	3700752	HOSE\HYD\1/2X70\3/4MORSX3/4MORS_90DE G	(RELIEF VALVE TO LOADER CYL ROD END)	1	EA.
30	3700753	HOSE\HYD\1/2X44\3/4MORSX3/4MORS_90DE G	(RELIEF VALVE TO LOADER CYL CAP END)	1	EA.
31	3701028	HOSE\HYD\1/4X95\9/16FJICX9/16FJIC	(FAN CYL CAP END TO AUX VALVE)	1	EA.
32	3701561	HOSE\HYD\1/2X138\7/8MORSX3/4FJIC	(FLOW CONTROL VALVE TO CONVEYOR ORBIT MOTOR)	1	EA.
33	3701561	HOSE\HYD\1/2X138\7/8MORSX3/4FJIC	(FLOW CONTROL VALVE TO CONVEYOR ORBIT MOTOR)	1	EA.

This page intentionally left blank

**2574 Hydraulic Assembly (for SN thru 0051)**


Item	Part No.	Name	Remarks	Qty	Uom
NS	7501088	CAP\PLSTC\#27\TAPERED\RED		4	EA.
NS	7501361	CAP\YELLOW\DUST\HOSE\HYD		2	EA.
NS	7501362	CAP\RED\DUST\HOSE\HYD		2	EA.




LOADER AND CONVEYOR ORBIT MOTOR


DETAIL B

FLOW CONTROL




FAN ORBIT MOTOR






FAN CYLINDER



HYD. VALVE CONNECTIONS



TRACTOR END CONNECTIONS

**2574 Hydraulic Assembly (for SN 0052 and up)**


Item	Part No.	Name	Remarks	Qty	Uom
1	3800328	FTG\7/8MORX3/4MJIC\ADPT		1	EA.
2	3800453	FTG\3/4MORX9/16MJIC\90		4	EA.
3	3800477	FTG\3/4MORX3/4MJIC\ST		3	EA.
4	3800483	FTG\3/4MORX3/4MJICX3/4MJIC\RUN;TEE		1	EA.
5	3800490	FTG\3/4MOR\PLUG\HEX		2	EA.
6	3800530	FTG\3/4MORX9/16MJIC\ST		2	EA.
7	3800537	FTG\3/4MORX3/4MJIC\90		1	EA.
8	3800538	FTG\7/8MORX9/16MJIC\90		2	EA.
9	3800683	FTG\3/4MOR\ORFICE\0.0490"		2	EA.
10	3800694	FTG\3/4FOR\QUICK;CPLR\FEMALE		4	EA.
11	3801014	FTG\9/16MJICX9/16FJIC\ORF-CK		2	EA.
12	3900025	MOTOR\HYD\17.9\HAMNT\7/8FOR\1SHFT		2	EA.
13	4000234	VALVE\RELIEF\CROSS\RC13BB		1	EA.
14	4000288	FTG\7/8MORX7/8MJIC\ST\CHCK		1	EA.
15	4000331	VALVE\FLW-CRTL\#8FOR		1	EA.
16	4000569	VLV\HYD\BRAND\4-BANK\00277		1	EA.
17	4100224	CYL\HYD\2-1/2X16\1-1/2ROD\3/4OR\RED		1	EA.
18	4100273	CYL\HYD\4-1/2X24\1-3/4 -CANADIAN TOOL & DIE		1	EA.
19	3701562	HOSE\HYD\1/4X11\9/16FJICX9/16FJIC	(FAN CYLINDER ROD END TO AUX VALVE)	1	EA.
20	3701563	HOSE\HYD\1/2X44\3/4MORSX3/4FJIC90	(AUX VALVE TO RELIEF VALVE)	1	EA.
21	3701563	HOSE\HYD\1/2X44\3/4MORSX3/4FJIC90	(AUX VALVE TO RELIEF VALVE)	1	EA.
22	3701619	HOSE\HYD\1/2X150\3/4FJICX3/4MOR	(FLOW CONTROL TO TRACTOR)	1	EA.
23	3701619	HOSE\HYD\1/2X150\3/4FJICX3/4MOR	(FLOW CONTROL TO TRACTOR)	1	EA.
24	3701705	HOSE\HYD\1/4X126\9/16FJICX9/16FJIC90S	(FAN ORBIT MOTOR TO AUX VALVE)	1	EA.
25	3701705	HOSE\HYD\1/4X126\9/16FJICX9/16FJIC90S	(FAN ORBIT MOTOR TO AUX VALVE)	1	EA.
26	3700748	HOSE\HYD\1/2X162\3/4MORSX3/4FJIC90	(AUX VALVE TO TRACTOR)	1	EA.
27	3700749	HOSE\HYD\1/2X162\3/4MORSX7/8FJIC90	(AUX VALVE TO TRACTOR)	1	EA.
28	3700752	HOSE\HYD\1/2X70\3/4MORSX3/4MORS_90DE G	(RELIEF VALVE TO LOADER CYL ROD END)	1	EA.
29	3700753	HOSE\HYD\1/2X44\3/4MORSX3/4MORS_90DE G	RELIEF VALVE TO LOADER CYL CAP END)	1	EA.
30	3701028	HOSE\HYD\1/4X95\9/16FJICX9/16FJIC	(FAN CYL CAP END TO AUX VALVE)	1	EA.
31	3701561	HOSE\HYD\1/2X138\7/8MORSX3/4FJIC	(FLOW CONTROL VALVE TO CONVEYOR ORBIT MOTOR)	1	EA.
32	3701561	HOSE\HYD\1/2X138\7/8MORSX3/4FJIC	(FLOW CONTROL VALVE TO CONVEYOR ORBIT MOTOR)	1	EA.
CA	3701560	HOSEKIT\2574			EA.



This page intentionally left blank

**2574 Hydraulic Assembly (for SN 0052 and up)**

Item	Part No.	Name	Remarks	Qty	Uom
NS	7501088	CAP\PLSTC\#27\TAPERED\RED		4	EA.
NS	7501361	CAP\YELLOW\DUST\HOSE\HYD		2	EA.
NS	7501362	CAP\RED\DUST\HOSE\HYD		2	EA.




---

**3900025 Orbit Motor Assembly**


---

Item	Part No.	Name	Remarks	Qty	Uom
1	3900025	MOTOR\HYD\17.9\HAMNT\7/8FOR\1SHFT			EA.
2	3900002	MOUNTING FLANGE		1	EA.
3	6200011	KEY\WDF\1/4X1		1	EA.
4	7501038	UNI SEAL KIT 007-009		1	EA.



## 4000331-Flow Control Valve


Item	Part No.	Name	Remarks	Qty	Uom
1	4000331	VALVE\FLW-CRTL\#8FOR			EA.
2	4000334	HDL\ASSY\V\HYD			EA.
3	4000335	SEAL\KIT\V\HYD			EA.
4	4000336	SNAP RING\V\HYD			EA.






# 4000569-Hydraulic Valve

Item	Part No.	Name	Remarks	Qty	Uom
1	4000176	VALVE\HYD\CART\WORK		8	EA.
2	4000179	VALVE\HYD\CART\UNLDR		1	EA.
3	4000197	VALVE\HYD\HIGHSEC\36SER		3	EA.
4	4000473	KIT\LOCK\LOAD		3	EA.
5	4000528	VALVE\HYD\UNLOADER\36\BRAND		1	EA.
6	4000533	VALVA\HYD\LOWSEC\36SER		1	EA.
8	5701141	SOL\HYD\12VDC\HYDRAFORCE		9	EA.
CA	4000569	VLV\HYD\BRAND\4-BANK\00277		1	EA.
NS	7501292	SEAL\KIT\VLV\BRAND\SECTION\WORK		4	EA.




## 2574 Joystick Control Box

Item	Part No.	Name	Remarks	Qty	Uom
1	5701167	JOYSTICK\CNTRBX\4-FNCTN\W-HR		1	EA.
2	5700333	SWITCH\RCKR\MNT\PNL\MTPL		2	EA.
3	5700542	SWITCH\RCKR\DPDT\24VUNLIT\15A\MOMNTR Y\W/RASED BRCKT		1	EA.
4	5700546	SWITCH\RCKR\DPDT\12V\2LIT		1	EA.
5	5700958	HARN\2564\CNTRLBX\4-FNCTN		1	EA.
6	5700858	SW\JOYSTICK\2;AXIS		1	EA.
7	5700859	GASKET\SWITCH\RCKR\CARLING		2	EA.
8	5700908	CONN\RECEPT\DTZ\16PIN\SZ24\CLAMP		1	EA.
9	5700909	CONN\PLUG\DTZ\16SCKT\SZ24\CLAMP		1	EA.
NS	5700528	FUSE\BLADE\ATO-ATC\5AMP			EA.
NS	7501494	ARM\SUPPORT\MONITOR			EA.



## 2574 Round Taillights - Standard Mounting


Item	Part No.	Name	Remarks	Qty	Uom
1	4800003	BOLT\HEX\3/8X1		4	EA.
2	4800277	BOLT\HEX\1/4X1		8	EA.
3	4900002	NUT\HEX\3/8\NC		4	EA.
4	4900040	NUT\FLG\SERR\1/4\NC		8	EA.
5	5000019	WASH\LOCK\3/8		4	EA.
6	5701058	TAILLIGHT\RED;R\LED\ASSY\4PIN		1	EA.
7	5701059	TAILLIGHT\RED;L\LED\ASSY\4PIN	N/A (Order 5701285 and 5701283)	1	EA.
8	8101527	BRKT\TAILLIGHT\2564\RH		1	EA.
9	8101528	BRKT\TAILLIGHT\2564\LH		1	EA.
	5701079	KIT\LIGHT\LED\2-LIGHT\4-PIN	(Includes #6, #7 and 5700924)	1	EA.



## 2574 Rectangular Taillights-Standard Mounting


Item	Part No.	Name	Remarks	Qty	Uom
1	4800003	BOLT\HEX\3/8X1		4	EA.
2	4800277	BOLT\HEX\1/4X1		8	EA.
3	4900002	NUT\HEX\3/8\NC		4	EA.
4	4900040	NUT\FLG\SERR\1/4\NC		8	EA.
5	5000019	WASH\LOCK\3/8		4	EA.
6	5701284	LGHT\TAIL\AMBER-LEFT\4PN-WP\LED		1	EA.
7	5701285	LGHT\TAIL\AMBER-RGHT\4PN-WP\LED		1	EA.
8	8101527	BRKT\TAILLIGHT\2564\RH		1	EA.
9	8101528	BRKT\TAILLIGHT\2564\LH		1	EA.
NS	5701296	HARN\TAIL;LIGHTS\SHREDDER\4FLAT		1	EA.
	5701301	KIT\LIGHT\2-4PIN.LED\60-74-1000	(Includes #6, #7 & 5701296 harness)		EA.
CA	8101529	LIGHTS\TRAVEL\KIT\2564\2574			EA.






## 2574 Optional Curved Spout

Item	Part No.	Name	Remarks	Qty	Uom
1	4800003	BOLT\HEX\3/8X1		5	EA.
2	4800277	BOLT\HEX\1/4X1		1	EA.
3	4900023	NUT\TPLCK\3/8\NC		5	EA.
4	4900084	NUT\TPLCK\1/4\NC		1	EA.
5	5000001	WASH\FLAT\3/8		7	EA.
6	8100247	BOLT\ADJ\SPOUT		1	EA.
7	8100257	BUSH\DFLCTR\SPOUT		2	EA.
8	8100299	STRAP\ADJ\SPOUT		1	EA.
9	8100500	DFLCTR\SPOUT\DISCH		1	EA.
10	8101298	SPOUT\NO3\2564		1	EA.
CA	8101691	#3\CURVED\SPOUT\KIT			EA.




## 2574 Optional 5-1/2 Ft. Straw Cannon Assembly

Item	Part No.	Name	Remarks	Qty	Uom
1	4800003	BOLT\HEX\3/8X1		2	EA.
2	4800277	BOLT\HEX\1/4X1		1	EA.
3	4900023	NUT\TPLCK\3/8\NC		2	EA.
4	4900084	NUT\TPLCK\1/4\NC		1	EA.
5	8101723	SPOUT\CANNON\5-1/2 FT		1	EA.
CA	8101746	#5\STRAW\CANNON\KIT			EA.
NS	6500276	DECAL\LOGO\STRAW;CANNON		2	EA.



## 2574 Optional Spout Hose Bracket


Item	Part No.	Name	Remarks	Qty	Uom
CA	8101758	KIT\HOSE\10"X25FT			EA.
1	4800003	BOLT\HEX\3/8X1		4	EA.
2	4900002	NUT\HEX\3/8\NC		4	EA.
3	5000019	WASH\LOCK\3/8		4	EA.
4	8101767	BRKT\HOSE\SPOUT		1	EA.
NS	3700847	HOSE\BLWR\10\25FT		1	EA.
NS	7501372	CLAMP\WORM\12\SWIVEL\LOCK		2	EA.
NS	8101756	COUPLER\10" HOSE\2564		1	EA.
NS	8101757	SPOUT\HANDLE\10" HOSE\2564		1	EA.



## 2574 Optional Spout Mini-Gun

Item	Part No.	Name	Remarks	Qty	Uom
1	4800003	BOLT\HEX\3/8X1		5	EA.
2	4800034	BOLT\HEX\3/8X1-1/2		2	EA.
3	4900002	NUT\HEX\3/8\NC		6	EA.
4	4900023	NUT\TPLCK\3/8\NC		1	EA.
5	4900076	NUT\FLG\SERR\3/8\NC		1	EA.
6	5000001	WASH\FLAT\3/8		7	EA.
7	5000019	WASH\LOCK\3/8		6	EA.
8	8100247	BOLT\ADJ\SPOUT		1	EA.
9	8100299	STRAP\ADJ\SPOUT		1	EA.
10	8101768	SPOUT\MINI-GUN		1	EA.
11	8101769	DFLCTR\SPOUT\DISCH		1	EA.
12	8101776	BSH\SPOUT\11/16"		2	EA.
CA	8101782	SPOUT\MINI-GUN\KIT			EA.






## 2574 Optional 80 Degree Spout

Item	Part No.	Name	Remarks	Qty	Uom
1	4800003	BOLT\HEX\3/8X1		2	EA.
2	4800277	BOLT\HEX\1/4X1		1	EA.
3	4900023	NUT\TPLCK\3/8\NC		2	EA.
4	4900084	NUT\TPLCK\1/4\NC		1	EA.
5	8102049	SPOUT\3FT\HOSE\2564		1	EA.


Note: Move hub and spindle to upper set of holes in the main frame when using the Flotation Tires.



Note - Optional Fenders can not be used with Optional Flotation Tires


**2574 Optional Flotation Tires**

Item	Part No.	Name	Remarks	Qty	Uom
CA	2600849	WHL\IMP-2\ASSY\14LX16.1	(Includes (2) of each item #1 and #2)	1	EA.
1	2600846	TIRE\14LX16.1\8PLY		2	EA.
2	2600652	WHL\6-BOLT\16.1X11		2	EA.
CA	2600848	WHL\IMP-1\ASSY\14LX16.1	(Includes (1) of each item #1 and #2)	2	EA.



## Optional Axle Extensions


Item	Part No.	Name	Remarks	Qty	Uom
1	4800350	BOLT\HEX\5/8X2-1/4		8	EA.
2	4900005	NUT\HEX\5/8\NC		8	EA.
3	5000003	WASH\LOCK\5/8		8	EA.
4	8101267	EXTENSION\AXLE\12"		2	EA.
CA	8101276	EXTENSION\AXLE\KIT			EA.



**2574 Optional 2nd Axle with Highway Tires Only**


Item	Part No.	Name	Remarks	Qty	Uom
1	2600624	Wheel, 15" x 10 6-Bolt		2	EA.
2	2600041	Tire\31X10.5X15 Highway Tire		2	EA.
3	2900171	HUB\6-BOLT\STUDS\COMPLETE		2	EA.
4	4800200	BOLT\L\3/4X5-1/4X8-1/4		4	EA.
5	4800350	BOLT\HEX\5/8X2-1/4		8	EA.
6	4900004	NUT\HEX\3/4\NC		8	EA.
7	4900005	NUT\HEX\5/8\NC		8	EA.
8	5000003	WASH\LOCK\5/8		8	EA.
9	5000005	WASH\FLAT\3/4		4	EA.
10	5000012	WASH\LOCK\3/4		8	EA.
11	8101828	SPNDL\BOLT-ON\HVY_DUTY		2	EA.
12	8101972	AXLE\OPTION\2574		1	EA.
CA	8101912	OPT\ASSY\AXLE\SECOND\2574			EA.
CA	2600823	WHL\HWY\31X10.5X15\TIRE&RIM	(Includes (1) each of #1 and #2)		EA.
CA	8101958	SPNDL\HUB\STUD\ASSY\	(Includes (1) of each #3 and #11)		EA.






**2574 Optional Shredder Extension Assembly**

Item	Part No.	Name	Remarks	Qty	Uom
1	4800003	BOLT\HEX\3/8X1		12	EA.
2	4900002	NUT\HEX\3/8\NC		12	EA.
3	5000001	WASH\FLAT\3/8		9	EA.
4	5000019	WASH\LOCK\3/8		12	EA.
5	8101977	SHLD\FR\SHREDDER		1	EA.
6	8101978	EXT\SIDE\SHREDDER		1	EA.




## 2574 Optional Containment Flap Assembly

Item	Part No.	Name	Remarks	Qty	Uom
1	4800034	BOLT\HEX\3/8X1-1/2		1	EA.
2	4800068	BOLT\HEX\1/2X3		1	EA.
3	4900001	NUT\HEX\1/2\NC		1	EA.
4	4900002	NUT\HEX\3/8\NC		1	EA.
5	5000004	WASH\FLAT\1/2		1	EA.
6	5000006	WASH\LOCK\1/2		1	EA.
7	5000019	WASH\LOCK\3/8		1	EA.
8	6100078	SPG\DR\TUB		1	EA.
9	8101980	FLAP-CON-KIT\2574		1	EA.
10	8101981	MNT\SPNG\CON-KIT\2574		1	EA.
11	8101982	MNT\FLAP\CON-KIT\2574		1	EA.
CA	8101983	KIT\FLAP\CON\2574			EA.



## 2574 Optional Hydraulic Slug Bar

Item	Part No.	Name	Remarks	Qty	Uom
1	3800453	FTG\3\4MORX9\16MJIC\90		4	EA.
2	3800683	FTG\3\4MOR\ORFICE\0.0490"		2	EA.
3	4000569	VLV\HYD\BRAND\4-BANK\00277		1	EA.
4	4100326	CYL\HYD\2X18\1-1/4ROD-RAM INDUSTRIES		1	EA.
5	4800003	BOLT\HEX\3\8X1		4	EA.
6	4800120	PIN\COT\3\16X1-3/4		2	EA.
7	4800143	SCR\SET\ALN\3\8X3\8\NC		2	EA.
8	4800185	PIN\CLEVIS\1X3		2	EA.
9	4900002	NUT\HEX\3\8\NC		4	EA.
10	5000001	WASH\FLAT\3\8		4	EA.
11	5000019	WASH\LOCK\3\8		4	EA.
12	6200021	KEY\SQ\3\8X1-1/2\HARDEND		1	EA.
13	8101038	BRKT\INDEX\SLUGBAR		1	EA.
14	8101880	MNT\CYL\HYD\SLGBR\2574		1	EA.
15	8101881	MNT\CYL\SHRDR\SLGBR		1	EA.
16	3701671	HOSE\HYD\1\4X98\9\16FJIC\9\16FJIC		1	EA.
17	3701672	HOSE\HYD\1\4X80\9\16FJIC\9\16FJIC		1	EA.
CA	8102140	CNTRL\SLGBR\HYD\KIT\2574			EA.



## 2574 Optional Hydraulic Rack Assembly


Item	Part No.	Name	Remarks	Qty	Uom
1	3701672	HOSE\HYD\1/4X80\9/16FJIC\9/16FJIC		1	EA.
2	3701672	HOSE\HYD\1/4X80\9/16FJIC\9/16FJIC		1	EA.
3	3800453	FTG\3/4MORX9/16MJIC\90		1	EA.
4	3800530	FTG\3/4MORX9/16MJIC\ST		3	EA.
5	3800683	FTG\3/4MOR\ORFICE\0.0490"		2	EA.
6	4100262	CYL\HYD\2X12\1-1/4TUBE		1	EA.
7	4800003	BOLT\HEX\3/8X1		4	EA.
8	4800018	BOLT\HEX\1/2X1-1/4		4	EA.
9	4800082	BOLT\HEX\1/2X1-1/2		1	EA.
10	4800120	PIN\COT\3/16X1-3/4		2	EA.
11	4800185	PIN\CLEVIS\1X3		1	EA.
12	4800977	PIN\CLEVIS\1X3-1/4		1	EA.
13	4900001	NUT\HEX\1/2\NC		5	EA.
14	4900002	NUT\HEX\3/8\NC		4	EA.
15	5000001	WASH\FLAT\3/8		4	EA.
16	5000006	WASH\LOCK\1/2		5	EA.
17	5000019	WASH\LOCK\3/8		4	EA.
18	8101098	BRKT\STRAP\RACK\HOOK\2650		1	EA.
19	8102005	STRAP\RACK\HOOK\REAR		1	EA.
20	8102339	MNT\CYL\RACK\2574		1	EA.
21	8102342	MNT\CYL\SHRDR\RACK-SLGBR\2574		1	EA.
22	8102345	EXT\HANGER\PTO		1	EA.
23	8102346	MNT\EXT\HANGER\PTO		1	EA.
24	8102347	MNT\EXT\HANGER\PTO		1	EA.
CA	8102341	CNTRL\RACK\HYD\KIT\2574			EA.



## 2574 Balebuster Parts Reference



1 - 6500034



2 - 6500035




3 - 6500036




6 - 6500082



8 - 6500304



4 - 6500040




5 - 6500041




7 - 6500085




17 - 6500542



9 - 6500322




11 - 6500417



12 - 6500418



21 - 7501701



15 - 6500488



18 - 6500546

EXTEND LOADER CYLINDER FULLY. REMOVE THE PINS, AND PLACE THEM IN THE LOWEST HOLE IN THE BRACKET.


10 - 6500361




13 - 6500434



14 - 6500435



16 - 6500518




19 - 6500549





20 - 7501353


## 2574 Decals

Item	Part No.	Name	Remarks	Qty	Uom
1	6500034	DECAL\DNGR\FLYG;HAY\RACK		2	EA.
2	6500035	DECAL\DNGR\ROTATNG;FLAILS		1	EA.
3	6500036	DECAL\INFO\BALE;ROTATION>		1	EA.
4	6500040	DECAL\WARN\SHIELD\PROT		2	EA.
5	6500041	DECAL\WARN\PROTECTION		1	EA.
6	6500082	DECAL\DNGR\ROTATN;PART;>		1	EA.
7	6500085	DECAL\DNGR\ROTATNG;DR-LNE		1	EA.
8	6500304	DECAL\LOGO\HYBST\1-3/4W/		1	EA.
9	6500322	DECAL\CAUTION\ADJ.DRAWBAR		1	EA.
10	6500361	DECAL\PIN\LOADER\2650		2	EA.
11	6500417	DECAL\GREASE\10 HRS		9	EA.
12	6500418	DECAL\GREASE\40 HRS		1	EA.
13	6500434	DECAL\2X9\RED\REFCT		5	EA.
14	6500435	DECAL\2X9\AMBER\REFCT		5	EA.
15	6500488	DECAL\WARN\PARTS\MOVING		3	EA.
16	6500518	DECAL\INDEX\SLUGBAR\2574		1	EA.
17	6500542	DECAL\LOGO\2574W\STRIPE		2	EA.
18	6500546	DECAL\BOLTS\FLAIL\156 FT-LBS		1	EA.
19	6500549	DECAL\WARN\PPE		1	EA.
20	7501353	SIGN\SMV\PLSTC-BCKNG		1	EA.
21	7501701	DECAL\ASSY\ID\SPD\25MPH/40KM/H		1	EA.
CA	6500519	DECAL\KIT\2574		1	EA.
NS	7500077	Yellow Spray Paint	ORDER 7500980		EA.
NS	7500092	Yellow Paint			EA.
NS	7500091	Yellow Paint			EA.
NS	7500078	Red Spray Paint			EA.
NS	7500105	Red Paint			EA.
NS	7500104	Red Paint			EA.













4000569  
FRONT

















## Delivery Report

Delivery Date	Machine Model	Serial No.	
Dealer Name		Engine Serial No.	
Dealer Address		Invoice No.	
Dealer City	State	Zip	
Dealer Email		Phone	

Customer Name		
Customer Address		Phone
Customer City	State	Zip
Customer Email		

The following items are to be checked as they are explained to the owner / operator at the time of delivery

- ☐ Explain the delivery packet and present the operators manual(s) to the owner / operator.
- ☐ Review and inspect the machine safety signs (decals) and the operator's manual.
- ☐ Advise the owner that the dealer is the source to obtain operator training, and information regarding the correct application of the machine to the job, as well as service and warranty information.
- ☐ Explain the capabilities and restrictions of the machine as it applies to the owner's application as defined in the operator's manual.
- ☐ Explain the operation of the controls and start up and shut down procedures of the engine and power transmission components of the machine.
- ☐ Explain rated lift or carrying capacity and loading and unloading procedures of the machine to maintain safety and stability of the machine.
- ☐ Explain proper folding, unfolding, and transporting procedures to the owner / operator.
- ☐ Explain recommended fueling procedures on engine equipped machines.
- ☐ Explain proper loading and unloading of materials from the tub or grinding chamber of the machine.
- ☐ Objects thrown by shredding or spinning rotors may represent a hazard to personnel and property in the area. Minimize risks by planning and by keeping personnel and property clear of hazard area.
- ☐ Explain the availability and use of the tub cover to further reduce risks of thrown objects.
- ☐ Review maintenance and lubrication procedures with the operator / maintenance person as defined in the operators manual.
- ☐ Advise never to use the machine in an environment with explosive or flammable materials present.
- ☐ Explain warranty policy and limitations to the owner / operator.



### Warning

**Misuse of the machine or modification or removal of the guards, safety devices, or control interlocks can cause injury or death.**

The above delivery information has been explained to me. I understand the operation and maintenance of this machine. I also acknowledge the warranty conditions and limitations as outlined.	
Owner / Operator Signature	Date
Dealer Representative Signature	Date

